



GENERAL NOTES:

1) USE ON ALL T2000 W/ CUMMINS ENGINE.

2) THIS DIAGRAM APPLIES TO CHASSIS BUILT
STARTING APPROX 1996
ENDING APPROX XXXX XXXX

3)  DENOTES "TWISTED PAIR" OF WIRES.4)  DENOTES "TWISTED TRIPLES" OF WIRES.

5) SUPERSEDES P94-1001



FLAG NOTES:

1 > BLACK 76-WAY AT RH FIREWALL

2 > BLACK PACKARD METRI-PACK AT RH LOWER FIREWALL

3 > BLACK PACKARD WEATHERPACK NEAR RH AIR TANKS

4) BLACK AMP CONNECTOR:

4A > NEAR "B" PANEL

4B > AT LOWER RH "A" PANEL

5) BLACK MOLDED SPADE CONNECTOR:

5A > AT LOWER LH "A" PANEL

5B > AT LOWER RH "A" PANEL

6 > GRAY DEUTSCH HD SERIES AT ECM

7 > BLACK PACKARD METRI-PACK AT LOW COOLANT SENSOR

8 > GRAY DEUTSCH DT SERIES BELOW RH "A" PANEL

9 > BLACK PACKARD METRI-PACK NEAR ECM

10 > BLACK PACKARD METRI-PACK AT SPEED SENSOR

11 > GRAY DEUTSCH DT SERIES AT RH LOWER FIREWALL BEHIND ENGINE

12 > NATURAL MOLEX CONNECTOR NEAR "B" PANEL

