


GENERAL NOTES:

1) USE ON ALL T2000 MODELS.

2) THIS DIAGRAM APPLIES TO CHASSIS BUILT
STARTING APPROX OCT 1996
ENDING APPROX XXXX XXXX

3)  DENOTES "TWISTED PAIR" OF WIRES.

4) SUPERSEDES P94-1003, -1007, -1011

FLAG NOTES:

1 > BLACK 76-WAY AT RH FIREWALL

2) NATURAL MOLEX CONNECTOR:

 BEHIND "A" PANEL BEHIND "B" PANEL

3 > BLACK MOLDED SPADE BEHIND "B" PANEL

4 > WHITE PACKARD METRI-PACK AT LOWER RH "B" PANEL

5 > GRAY DEUTSCH HD SERIES AT LH LOWER "A" PANEL

6 > EYELET TERMINAL AT FUEL SENDER

7 > BLACK PACKARD METRI-PACK AT LOWER RH "A" PANEL

8 > GRAY DEUTSCH DT SERIES NEAR LOWER RH FIREWALL

9 > BLACK PACKARD METRI-PACK NEAR LOWER RH FIREWALL

10 > BLACK PACKARD METRI-PACK AT TRANSMISSION TEMP SENSOR

11 > GRAY DEUTSCH DT SERIES AT RH RAIL NEAR TRANSMISSION

12 > BLACK PACKARD METRI-PACK AT REAR AXLE

13 > BLACK PACKARD METRI-PACK AT FORWARD REAR AXLE

14 > BLACK PACKARD METRI-PACK AT FORWARD REAR CROSSMEMBER

15 > BLACK PACKARD METRI-PACK AT REAR RH AIR TANKS

