



GENERAL NOTES:

1) USE ON ALL T2000

2)

3) SUPERSEDES P94-1002, -1006, -1010

FIG 1	1
FIG 2	2

FLAG NOTES:

1) STANDARD JUMPER FOR USE WITHOUT MPX WHEEL

2) BLACK PACKARD METRI-PACK BELOW "A" PANEL

3) BLACK MOLDED SPADE NEAR LOWER RH "B" PANEL

4) BLACK AMP CONNECTOR:

4A) NEAR "B" PANEL

4B) NEAR LOWER LH "A" PANEL

5) BLACK PACKARD METRI-PACK BEHIND LH GLOVEBOX

6) BLACK PACKARD METRI-PACK BEHIND RH KICKPANEL

7) BLACK 76-WAY AT RH FIREWALL

8) GRAY DEUTSCH DT SERIES CONNECTOR:

8A) BEHIND RH HEADLAMP

8B) BEHIND LH HEADLAMP

9) BLACK PACKARD METRI-PACK CONNECTOR:

9A) BEHIND RH HEADLAMP

9B) BEHIND LH HEADLAMP

10) WHITE PACKARD METRI-PACK CONNECTOR:

10A) BEHIND RH UPPER SIDE PANEL BEHIND DOOR

10B) BEHIND RH LOWER SIDE PANEL BEHIND DOOR

10C) BEHIND RH KICK PANEL

11) BLACK PACKARD METRI-PACK BEHIND RH UPPER SIDE PANEL BEHIND DOOR

12) BLACK PACKARD METRI-PACK CONNECTOR:

12A) BEHIND LH LOWER BACK PANEL

12B) BEHIND RH LOWER BACK PANEL

