



GENERAL NOTES:

- 1) USE ON ALL T2000 FOR TURN/TRAILER WIRING.

- 3) SUPERSEDES P94-1012 .

PROD	X
SERV	X

FLAG NOTES:

- 1) BLACK 76-WAY AT RH FIREWALL
- 2) EYELET TERMINAL BELOW RH "A" PANEL
- 3) BLACK PACKARD METRI-PACK 630 SERIES BELOW STEERING COLUMN
- 4) BLACK PACKARD METRI-PACK BELOW STEERING COLUMN
- 5) BLACK PACKARD METRI-PACK 630 SERIES BELOW STEERING COLUMN
- 6) BLACK PACKARD METRI-PACK BELOW GLOVE BOX.
- 7) GRAY DEUTSCH DT SERIES CONNECTOR:
  - 7A) BELOW LH RADIATOR
  - 7B) BELOW RH RADIATOR
  - 7C) BELOW LH FIREWALL
  - 7D) BELOW RH FIREWALL
- 8) BLACK PACKARD METRI-PACK AT BACKUP LAMP SWITCH
- 9) GRAY DEUTSCH DT SERIES AT RH LOWER FIREWALL
- 10) BLACK 7-WAY TRAILER PLUG AT BACK OF CAB
- 11) GRAY PACKARD METRI-PACK CONNECTOR:
  - 11A) AT LH TAIL LAMP
  - 11B) AT RH TAIL LAMP

## USAGE NOTE:

- 1) USE ON ALL T2000 FOR TURN/TRAILER WIRING.

