

GENERAL NOTES:

- 1) USE FOR T2000 WITH STANDARD HVAC AND APADS CONTROL SYSTEM.

- 3) SUPERSEDES P94-1015 .

PROD	X
SERV	X

FLAG NOTE:

- 1) BLACK PACKARD METRI-PACK 630 SERIES CONNECTOR:

1A > BEHIND LOWER "B" PANEL

2B > BEHIND CAB HVAC CONTROL PANEL

- 2) WHITE PACKARD METRI-PACK 280 SERIES CONNECTOR:

2A > BEHIND LOWER "B" PANEL

2B > BEHIND RH KICK PANEL

2C > NEAR RH DOOR BOTTOM BACK EDGE

2D > BEHIND RH KICK PANEL

2E > NEAR RH DOOR TOP BACK EDGE

2F > BEHIND SLEEPER HVAC CONTROL PANEL

2G > BEHIND CAB HVAC CONTROL PANEL

3 > BLACK PACKARD METRI-PACK 280 SERIES AT BACK OF SLEEPER LH SIDE

4 > BLACK PACKARD METRI-PACK 280 SERIES AT SLEEPER HEATER UNIT

- 5) BLACK PACKARD METRI-PACK 280 SERIES CONNECTOR:

5A > BEHIND CENTER FRONT TOP HEADER PANEL

5B > NEAR FREON COMPRESSOR

6 > WHITE 76-WAY CONNECTOR AT RH FIREWALL

7 > BLACK PACKARD METRI-PACK 280 SERIES BEHIND RH KICK PANEL

8 > BLACK PACKARD METRI-PACK 150 SERIES NEAR OUTSIDE AIR TEMP SENSOR

9 > BEFORE 3/9/98 (ECN9702255):

SEPERATE WIRE JUMPER (VENDOR# 660476) FROM TEMP SENSOR TO

CAB UNIT BEHIND LOWER "B" PANEL

AFTER 3/9/98:

AS SHOWN IN DIAGRAM ON SHEET 2

