

| Ametek Speedometer Calibration Codes, 58 to 92 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 58 = | ON | OFF | ON | OFF | OFF | OFF | ON | ON | ON | ON |
| 59 = | OFF | OFF | ON | OFF | OFF | OFF | ON | ON | ON | ON |
| 60 = | ON | ON | OFF | OFF | OFF | OFF | ON | ON | ON | ON |
| 61 = | OFF | ON | OFF | OFF | OFF | OFF | ON | ON | ON | ON |
| 62 = | ON | OFF | OFF | OFF | OFF | OFF | ON | ON | ON | ON |
| 63 = | OFF | OFF | OFF | OFF | OFF | OFF | ON | ON | ON | ON |
| 64 = | ON | ON | ON | ON | ON | ON | OFF | ON | ON | ON |
| 65 = | OFF | ON | ON | ON | ON | ON | OFF | ON | ON | ON |
| 66 = | ON | OFF | ON | ON | ON | ON | OFF | ON | ON | ON |
| 67 = | OFF | OFF | ON | ON | ON | ON | OFF | ON | ON | ON |
| 68 = | ON | ON | OFF | ON | ON | ON | OFF | ON | ON | ON |
| 69 = | OFF | ON | OFF | ON | ON | ON | OFF | ON | ON | ON |
| 70 = | ON | OFF | OFF | ON | ON | ON | OFF | ON | ON | ON |
| 71 = | OFF | OFF | OFF | ON | ON | ON | OFF | ON | ON | ON |
| 72 = | ON | ON | ON | OFF | ON | ON | OFF | ON | ON | ON |
| 73 = | OFF | ON | ON | OFF | ON | ON | OFF | ON | ON | ON |
| 74 = | ON | OFF | ON | OFF | ON | ON | OFF | ON | ON | ON |
| 75 = | OFF | OFF | ON | OFF | ON | ON | OFF | ON | ON | ON |
| 76 = | ON | ON | OFF | OFF | ON | ON | OFF | ON | ON | ON |
| 77 = | OFF | ON | OFF | OFF | ON | ON | OFF | ON | ON | ON |
| 78 = | ON | OFF | OFF | OFF | ON | ON | OFF | ON | ON | ON |
| 79 = | OFF | OFF | OFF | OFF | ON | ON | OFF | ON | ON | ON |
| 80 = | ON | ON | ON | ON | OFF | ON | OFF | ON | ON | ON |
| 81 = | OFF | ON | ON | ON | OFF | ON | OFF | ON | ON | ON |
| 82 = | ON | OFF | ON | ON | OFF | ON | OFF | ON | ON | ON |
| 83 = | OFF | OFF | ON | ON | OFF | ON | OFF | ON | ON | ON |
| 84 = | ON | ON | OFF | ON | OFF | ON | OFF | ON | ON | ON |
| 85 = | OFF | OFF | OFF | ON | OFF | ON | OFF | ON | ON | ON |
| 86 = | ON | OFF | OFF | ON | OFF | ON | OFF | ON | ON | ON |
| 87 = | OFF | OFF | OFF | ON | OFF | ON | OFF | ON | ON | ON |
| 88 = | ON | ON | ON | OFF | OFF | ON | OFF | ON | ON | ON |
| 89 = | OFF | ON | ON | OFF | OFF | ON | OFF | ON | ON | ON |
| 90 = | ON | OFF | ON | OFF | OFF | ON | OFF | ON | ON | ON |
| 91 = | OFF | OFF | ON | OFF | OFF | ON | OFF | ON | ON | ON |
| 92 = | ON | ON | OFF | OFF | OFF | ON | OFF | ON | ON | ON |

Table 1, Ametek Speedometer Calibration Codes, 58 to 92

Specifications

| Ametek Speedometer Calibration Codes, 93 to 129 | | | | | | | | | | |
|---|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 93 = | OFF | ON | OFF | OFF | OFF | ON | OFF | ON | ON | ON |
| 94 = | ON | OFF | OFF | OFF | OFF | ON | OFF | ON | ON | ON |
| 95 = | OFF | OFF | OFF | OFF | OFF | ON | OFF | ON | ON | ON |
| 96 = | ON | ON | ON | ON | ON | OFF | OFF | ON | ON | ON |
| 97 = | OFF | ON | ON | ON | ON | OFF | OFF | ON | ON | ON |
| 98 = | ON | OFF | ON | ON | ON | OFF | OFF | ON | ON | ON |
| 99 = | OFF | OFF | ON | ON | ON | OFF | OFF | ON | ON | ON |
| 100 = | ON | ON | OFF | ON | ON | OFF | OFF | ON | ON | ON |
| 101 = | OFF | ON | OFF | ON | ON | OFF | OFF | ON | ON | ON |
| 102 = | ON | OFF | OFF | ON | ON | OFF | OFF | ON | ON | ON |
| 103 = | OFF | OFF | OFF | ON | ON | OFF | OFF | ON | ON | ON |
| 104 = | ON | ON | ON | OFF | ON | OFF | OFF | ON | ON | ON |
| 105 = | OFF | ON | ON | OFF | ON | OFF | OFF | ON | ON | ON |
| 106 = | ON | OFF | ON | OFF | ON | OFF | OFF | ON | ON | ON |
| 107 = | OFF | OFF | ON | OFF | ON | OFF | OFF | ON | ON | ON |
| 108 = | ON | ON | OFF | OFF | ON | OFF | OFF | ON | ON | ON |
| 109 = | OFF | ON | OFF | OFF | ON | OFF | OFF | ON | ON | ON |
| 110 = | ON | OFF | OFF | OFF | ON | OFF | OFF | ON | ON | ON |
| 111 = | OFF | OFF | OFF | OFF | ON | OFF | OFF | ON | ON | ON |
| 112 = | ON | ON | ON | ON | OFF | OFF | OFF | ON | ON | ON |
| 113 = | OFF | ON | ON | ON | OFF | OFF | OFF | ON | ON | ON |
| 114 = | ON | OFF | ON | ON | OFF | OFF | OFF | ON | ON | ON |
| 115 = | OFF | OFF | ON | ON | OFF | OFF | OFF | ON | ON | ON |
| 116 = | ON | ON | OFF | ON | OFF | OFF | OFF | ON | ON | ON |
| 117 = | OFF | ON | OFF | ON | OFF | OFF | OFF | ON | ON | ON |
| 118 = | ON | OFF | OFF | ON | OFF | OFF | OFF | ON | ON | ON |
| 119 = | OFF | OFF | OFF | ON | OFF | OFF | OFF | ON | ON | ON |
| 120 = | ON | ON | ON | OFF | OFF | OFF | OFF | ON | ON | ON |
| 121 = | OFF | ON | ON | OFF | OFF | OFF | OFF | ON | ON | ON |
| 122 = | ON | OFF | ON | OFF | OFF | OFF | OFF | ON | ON | ON |
| 123 = | OFF | OFF | ON | OFF | OFF | OFF | OFF | ON | ON | ON |
| 124 = | ON | ON | OFF | OFF | OFF | OFF | OFF | ON | ON | ON |
| 125 = | OFF | ON | OFF | OFF | OFF | OFF | OFF | ON | ON | ON |
| 126 = | ON | OFF | OFF | OFF | OFF | OFF | OFF | ON | ON | ON |
| 127 = | OFF | OFF | OFF | OFF | OFF | OFF | OFF | ON | ON | ON |
| 128 = | ON | ON | ON | ON | ON | ON | ON | OFF | ON | ON |

| Ametek Speedometer Calibration Codes, 93 to 129 | | | | | | | | | | |
|---|-----|----|----|----|----|----|----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 129 = | OFF | ON | ON | ON | ON | ON | ON | OFF | ON | ON |

Table 2, Ametek Speedometer Calibration Codes, 93 to 129

| Ametek Speedometer Calibration Codes, 130 to 166 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 130 = | ON | OFF | ON | ON | ON | ON | ON | OFF | ON | ON |
| 131 = | OFF | OFF | ON | ON | ON | ON | ON | OFF | ON | ON |
| 132 = | ON | ON | OFF | ON | ON | ON | ON | OFF | ON | ON |
| 133 = | OFF | ON | OFF | ON | ON | ON | ON | OFF | ON | ON |
| 134 = | ON | OFF | OFF | ON | ON | ON | ON | OFF | ON | ON |
| 135 = | OFF | OFF | OFF | ON | ON | ON | ON | OFF | ON | ON |
| 136 = | ON | ON | ON | OFF | ON | ON | ON | OFF | ON | ON |
| 137 = | OFF | ON | ON | OFF | ON | ON | ON | OFF | ON | ON |
| 138 = | ON | OFF | ON | OFF | ON | ON | ON | OFF | ON | ON |
| 139 = | OFF | OFF | ON | OFF | ON | ON | ON | OFF | ON | ON |
| 140 = | ON | ON | OFF | OFF | ON | ON | ON | OFF | ON | ON |
| 141 = | OFF | ON | OFF | OFF | ON | ON | ON | OFF | ON | ON |
| 142 = | ON | OFF | OFF | OFF | ON | ON | ON | OFF | ON | ON |
| 143 = | OFF | OFF | OFF | OFF | ON | ON | ON | OFF | ON | ON |
| 144 = | ON | ON | ON | ON | OFF | ON | ON | OFF | ON | ON |
| 145 = | OFF | ON | ON | ON | OFF | ON | ON | OFF | ON | ON |
| 146 = | ON | OFF | ON | ON | OFF | ON | ON | OFF | ON | ON |
| 147 = | OFF | OFF | ON | ON | OFF | ON | ON | OFF | ON | ON |
| 148 = | ON | ON | OFF | ON | OFF | ON | ON | OFF | ON | ON |
| 149 = | OFF | ON | OFF | ON | OFF | ON | ON | OFF | ON | ON |
| 150 = | ON | OFF | OFF | ON | OFF | ON | ON | OFF | ON | ON |
| 151 = | OFF | OFF | OFF | ON | OFF | ON | ON | OFF | ON | ON |
| 152 = | ON | ON | ON | OFF | OFF | ON | ON | OFF | ON | ON |
| 153 = | OFF | ON | ON | OFF | OFF | ON | ON | OFF | ON | ON |
| 154 = | ON | OFF | ON | OFF | OFF | ON | ON | OFF | ON | ON |
| 155 = | OFF | OFF | ON | OFF | OFF | ON | ON | OFF | ON | ON |
| 156 = | ON | ON | OFF | OFF | OFF | ON | ON | OFF | ON | ON |
| 157 = | OFF | ON | OFF | OFF | OFF | ON | ON | OFF | ON | ON |
| 158 = | ON | OFF | OFF | OFF | OFF | ON | ON | OFF | ON | ON |
| 159 = | OFF | OFF | OFF | OFF | OFF | ON | ON | OFF | ON | ON |
| 160 = | ON | ON | ON | ON | ON | OFF | ON | OFF | ON | ON |

Specifications

| Ametek Speedometer Calibration Codes, 130 to 166 | | | | | | | | | | |
|--|-----|-----|-----|----|----|-----|----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 161 = | OFF | ON | ON | ON | ON | OFF | ON | OFF | ON | ON |
| 162 = | ON | OFF | ON | ON | ON | OFF | ON | OFF | ON | ON |
| 163 = | OFF | OFF | ON | ON | ON | OFF | ON | OFF | ON | ON |
| 164 = | ON | ON | OFF | ON | ON | OFF | ON | OFF | ON | ON |
| 165 = | OFF | ON | OFF | ON | ON | OFF | ON | OFF | ON | ON |
| 166 = | ON | OFF | OFF | ON | ON | OFF | ON | OFF | ON | ON |

Table 3, Ametek Speedometer Calibration Codes, 130 to 166

| Ametek Speedometer Calibration Codes, 167 to 203 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 167 = | OFF | OFF | OFF | ON | ON | OFF | ON | OFF | ON | ON |
| 168 = | ON | ON | ON | OFF | ON | OFF | ON | OFF | ON | ON |
| 169 = | OFF | ON | ON | OFF | ON | OFF | ON | OFF | ON | ON |
| 170 = | ON | OFF | ON | OFF | ON | OFF | ON | OFF | ON | ON |
| 171 = | OFF | OFF | ON | OFF | ON | OFF | ON | OFF | ON | ON |
| 172 = | ON | ON | OFF | OFF | ON | OFF | ON | OFF | ON | ON |
| 173 = | OFF | ON | OFF | OFF | ON | OFF | ON | OFF | ON | ON |
| 174 = | ON | OFF | OFF | OFF | ON | OFF | ON | OFF | ON | ON |
| 175 = | OFF | OFF | OFF | OFF | ON | OFF | ON | OFF | ON | ON |
| 176 = | ON | ON | ON | ON | OFF | OFF | ON | OFF | ON | ON |
| 177 = | OFF | ON | ON | ON | OFF | OFF | ON | OFF | ON | ON |
| 178 = | ON | OFF | ON | ON | OFF | OFF | ON | OFF | ON | ON |
| 179 = | OFF | OFF | ON | ON | OFF | OFF | ON | OFF | ON | ON |
| 180 = | ON | ON | OFF | ON | OFF | OFF | ON | OFF | ON | ON |
| 181 = | OFF | ON | OFF | ON | OFF | OFF | ON | OFF | ON | ON |
| 182 = | ON | OFF | OFF | ON | OFF | OFF | ON | OFF | ON | ON |
| 183 = | OFF | OFF | OFF | ON | OFF | OFF | ON | OFF | ON | ON |
| 184 = | ON | ON | ON | OFF | OFF | OFF | ON | OFF | ON | ON |
| 185 = | OFF | ON | ON | OFF | OFF | OFF | ON | OFF | ON | ON |
| 186 = | ON | OFF | ON | OFF | OFF | OFF | ON | OFF | ON | ON |
| 187 = | OFF | OFF | ON | OFF | OFF | OFF | ON | OFF | ON | ON |
| 188 = | ON | ON | OFF | OFF | OFF | OFF | ON | OFF | ON | ON |
| 189 = | OFF | ON | OFF | OFF | OFF | OFF | ON | OFF | ON | ON |
| 190 = | ON | OFF | OFF | OFF | OFF | OFF | ON | OFF | ON | ON |
| 191 = | OFF | OFF | OFF | OFF | OFF | OFF | ON | OFF | ON | ON |
| 192 = | ON | ON | ON | ON | ON | ON | OFF | OFF | ON | ON |

| Ametek Speedometer Calibration Codes, 167 to 203 | | | | | | | | | | |
|--|-----|-----|-----|-----|----|----|-----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 193 = | OFF | ON | ON | ON | ON | ON | OFF | OFF | ON | ON |
| 194 = | ON | OFF | ON | ON | ON | ON | OFF | OFF | ON | ON |
| 195 = | OFF | OFF | ON | ON | ON | ON | OFF | OFF | ON | ON |
| 196 = | ON | ON | OFF | ON | ON | ON | OFF | OFF | ON | ON |
| 197 = | OFF | ON | OFF | ON | ON | ON | OFF | OFF | ON | ON |
| 198 = | ON | OFF | OFF | ON | ON | ON | OFF | OFF | ON | ON |
| 199 = | OFF | OFF | OFF | ON | ON | ON | OFF | OFF | ON | ON |
| 200 = | ON | ON | ON | OFF | ON | ON | OFF | OFF | ON | ON |
| 201 = | OFF | ON | ON | OFF | ON | ON | OFF | OFF | ON | ON |
| 202 = | ON | OFF | ON | OFF | ON | ON | OFF | OFF | ON | ON |
| 203 = | OFF | OFF | ON | OFF | ON | ON | OFF | OFF | ON | ON |

Table 4, Ametek Speedometer Calibration Codes, 167 to 203

| Ametek Speedometer Calibration Codes, 204 to 240 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 204 = | ON | ON | OFF | OFF | ON | ON | OFF | OFF | ON | ON |
| 205 = | OFF | ON | OFF | OFF | ON | ON | OFF | OFF | ON | ON |
| 206 = | ON | OFF | OFF | OFF | ON | ON | OFF | OFF | ON | ON |
| 207 = | OFF | OFF | OFF | OFF | ON | ON | OFF | OFF | ON | ON |
| 208 = | ON | ON | ON | ON | OFF | ON | OFF | OFF | ON | ON |
| 209 = | OFF | ON | ON | ON | OFF | ON | OFF | OFF | ON | ON |
| 210 = | ON | OFF | ON | ON | OFF | ON | OFF | OFF | ON | ON |
| 211 = | OFF | OFF | ON | ON | OFF | ON | OFF | OFF | ON | ON |
| 212 = | ON | ON | OFF | ON | OFF | ON | OFF | OFF | ON | ON |
| 213 = | OFF | ON | OFF | ON | OFF | ON | OFF | OFF | ON | ON |
| 214 = | ON | OFF | OFF | ON | OFF | ON | OFF | OFF | ON | ON |
| 215 = | OFF | OFF | OFF | ON | OFF | ON | OFF | OFF | ON | ON |
| 216 = | ON | ON | ON | OFF | OFF | ON | OFF | OFF | ON | ON |
| 217 = | OFF | ON | ON | OFF | OFF | ON | OFF | OFF | ON | ON |
| 218 = | ON | OFF | ON | OFF | OFF | ON | OFF | OFF | ON | ON |
| 219 = | OFF | OFF | ON | OFF | OFF | ON | OFF | OFF | ON | ON |
| 220 = | ON | ON | OFF | OFF | OFF | ON | OFF | OFF | ON | ON |
| 221 = | OFF | ON | OFF | OFF | OFF | ON | OFF | OFF | ON | ON |
| 222 = | ON | OFF | OFF | OFF | OFF | ON | OFF | OFF | ON | ON |
| 223 = | OFF | OFF | OFF | OFF | OFF | ON | OFF | OFF | ON | ON |
| 224 = | ON | ON | ON | ON | ON | OFF | OFF | OFF | ON | ON |

Specifications

| Ametek Speedometer Calibration Codes, 204 to 240 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 225 = | OFF | ON | ON | ON | ON | OFF | OFF | OFF | ON | ON |
| 226 = | ON | OFF | ON | ON | ON | OFF | OFF | OFF | ON | ON |
| 227 = | OFF | OFF | ON | ON | ON | OFF | OFF | OFF | ON | ON |
| 228 = | ON | ON | OFF | ON | ON | OFF | OFF | OFF | ON | ON |
| 229 = | OFF | ON | OFF | ON | ON | OFF | OFF | OFF | ON | ON |
| 230 = | ON | OFF | OFF | ON | ON | OFF | OFF | OFF | ON | ON |
| 231 = | OFF | OFF | OFF | ON | ON | OFF | OFF | OFF | ON | ON |
| 232 = | ON | ON | ON | OFF | ON | OFF | OFF | OFF | ON | ON |
| 233 = | OFF | ON | ON | OFF | ON | OFF | OFF | OFF | ON | ON |
| 234 = | ON | OFF | ON | OFF | ON | OFF | OFF | OFF | ON | ON |
| 235 = | OFF | OFF | ON | OFF | ON | OFF | OFF | OFF | ON | ON |
| 236 = | ON | ON | OFF | OFF | ON | OFF | OFF | OFF | ON | ON |
| 237 = | OFF | ON | OFF | OFF | ON | OFF | OFF | OFF | ON | ON |
| 238 = | ON | OFF | OFF | OFF | ON | OFF | OFF | OFF | ON | ON |
| 239 = | OFF | OFF | OFF | OFF | ON | OFF | OFF | OFF | ON | ON |
| 240 = | ON | ON | ON | ON | OFF | OFF | OFF | OFF | ON | ON |

Table 5, Ametek Speedometer Calibration Codes, 204 to 240

| Ametek Speedometer Calibration Codes, 241 to 277 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 241 = | OFF | ON | ON | ON | OFF | OFF | OFF | OFF | ON | ON |
| 242 = | ON | OFF | ON | ON | OFF | OFF | OFF | OFF | ON | ON |
| 243 = | OFF | OFF | ON | ON | OFF | OFF | OFF | OFF | ON | ON |
| 244 = | ON | ON | OFF | ON | OFF | OFF | OFF | OFF | ON | ON |
| 245 = | OFF | ON | OFF | ON | OFF | OFF | OFF | OFF | ON | ON |
| 246 = | ON | OFF | OFF | ON | OFF | OFF | OFF | OFF | ON | ON |
| 247 = | OFF | OFF | OFF | ON | OFF | OFF | OFF | OFF | ON | ON |
| 248 = | ON | ON | ON | OFF | OFF | OFF | OFF | OFF | ON | ON |
| 249 = | OFF | ON | ON | OFF | OFF | OFF | OFF | OFF | ON | ON |
| 250 = | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF | ON | ON |
| 251 = | OFF | OFF | ON | OFF | OFF | OFF | OFF | OFF | ON | ON |
| 252 = | ON | ON | OFF | OFF | OFF | OFF | OFF | OFF | ON | ON |
| 253 = | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF | ON | ON |
| 254 = | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF | ON | ON |
| 255 = | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF | ON | ON |
| 256 = | ON | ON | ON | ON | ON | ON | ON | ON | OFF | ON |

| Ametek Speedometer Calibration Codes, 241 to 277 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|----|----|----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 257 = | OFF | ON | ON | ON | ON | ON | ON | ON | OFF | ON |
| 258 = | ON | OFF | ON | ON | ON | ON | ON | ON | OFF | ON |
| 259 = | OFF | OFF | ON | ON | ON | ON | ON | ON | OFF | ON |
| 260 = | ON | ON | OFF | ON | ON | ON | ON | ON | OFF | ON |
| 261 = | OFF | ON | OFF | ON | ON | ON | ON | ON | OFF | ON |
| 262 = | ON | OFF | OFF | ON | ON | ON | ON | ON | OFF | ON |
| 263 = | OFF | OFF | OFF | ON | ON | ON | ON | ON | OFF | ON |
| 264 = | ON | ON | ON | OFF | ON | ON | ON | ON | OFF | ON |
| 265 = | OFF | ON | ON | OFF | ON | ON | ON | ON | OFF | ON |
| 266 = | ON | OFF | ON | OFF | ON | ON | ON | ON | OFF | ON |
| 267 = | OFF | OFF | ON | OFF | ON | ON | ON | ON | OFF | ON |
| 268 = | ON | ON | OFF | OFF | ON | ON | ON | ON | OFF | ON |
| 269 = | OFF | ON | OFF | OFF | ON | ON | ON | ON | OFF | ON |
| 270 = | ON | OFF | OFF | OFF | ON | ON | ON | ON | OFF | ON |
| 271 = | OFF | OFF | OFF | OFF | ON | ON | ON | ON | OFF | ON |
| 272 = | ON | ON | ON | ON | OFF | ON | ON | ON | OFF | ON |
| 273 = | OFF | ON | ON | ON | OFF | ON | ON | ON | OFF | ON |
| 274 = | ON | OFF | ON | ON | OFF | ON | ON | ON | OFF | ON |
| 275 = | OFF | OFF | ON | ON | OFF | ON | ON | ON | OFF | ON |
| 276 = | ON | ON | OFF | ON | OFF | ON | ON | ON | OFF | ON |
| 277 = | OFF | ON | OFF | ON | OFF | ON | ON | ON | OFF | ON |

Table 6, Ametek Speedometer Calibration Codes, 241 to 277

| Ametek Speedometer Calibration Codes, 278 to 314 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|----|----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 278 = | ON | OFF | OFF | ON | OFF | ON | ON | ON | OFF | ON |
| 279 = | OFF | OFF | OFF | ON | OFF | ON | ON | ON | OFF | ON |
| 280 = | ON | ON | ON | OFF | OFF | ON | ON | ON | OFF | ON |
| 281 = | OFF | ON | ON | OFF | OFF | ON | ON | ON | OFF | ON |
| 282 = | ON | OFF | ON | OFF | OFF | ON | ON | ON | OFF | ON |
| 283 = | OFF | OFF | ON | OFF | OFF | ON | ON | ON | OFF | ON |
| 284 = | ON | ON | OFF | OFF | OFF | ON | ON | ON | OFF | ON |
| 285 = | OFF | ON | OFF | OFF | OFF | ON | ON | ON | OFF | ON |
| 286 = | ON | OFF | OFF | OFF | OFF | ON | ON | ON | OFF | ON |
| 287 = | OFF | OFF | OFF | OFF | OFF | ON | ON | ON | OFF | ON |
| 288 = | ON | ON | ON | ON | ON | OFF | ON | ON | OFF | ON |

Specifications

| Ametek Speedometer Calibration Codes, 278 to 314 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|----|----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 289 = | OFF | ON | ON | ON | ON | OFF | ON | ON | OFF | ON |
| 290 = | ON | OFF | ON | ON | ON | OFF | ON | ON | OFF | ON |
| 291 = | OFF | OFF | ON | ON | ON | OFF | ON | ON | OFF | ON |
| 292 = | ON | ON | OFF | ON | ON | OFF | ON | ON | OFF | ON |
| 293 = | OFF | ON | OFF | ON | ON | OFF | ON | ON | OFF | ON |
| 294 = | ON | OFF | OFF | ON | ON | OFF | ON | ON | OFF | ON |
| 295 = | OFF | OFF | OFF | ON | ON | OFF | ON | ON | OFF | ON |
| 296 = | ON | ON | ON | OFF | ON | OFF | ON | ON | OFF | ON |
| 297 = | OFF | ON | ON | OFF | ON | OFF | ON | ON | OFF | ON |
| 298 = | ON | OFF | ON | OFF | ON | OFF | ON | ON | OFF | ON |
| 299 = | OFF | OFF | ON | OFF | ON | OFF | ON | ON | OFF | ON |
| 300 = | ON | ON | OFF | OFF | ON | OFF | ON | ON | OFF | ON |
| 301 = | OFF | ON | OFF | OFF | ON | OFF | ON | ON | OFF | ON |
| 302 = | ON | OFF | OFF | OFF | ON | OFF | ON | ON | OFF | ON |
| 303 = | OFF | OFF | OFF | OFF | ON | OFF | ON | ON | OFF | ON |
| 304 = | ON | ON | ON | ON | OFF | OFF | ON | ON | OFF | ON |
| 305 = | OFF | ON | ON | ON | OFF | OFF | ON | ON | OFF | ON |
| 306 = | ON | OFF | ON | ON | OFF | OFF | ON | ON | OFF | ON |
| 307 = | OFF | OFF | ON | ON | OFF | OFF | ON | ON | OFF | ON |
| 308 = | ON | ON | OFF | ON | OFF | OFF | ON | ON | OFF | ON |
| 309 = | OFF | ON | OFF | ON | OFF | OFF | ON | ON | OFF | ON |
| 310 = | ON | OFF | OFF | ON | OFF | OFF | ON | ON | OFF | ON |
| 311 = | OFF | OFF | OFF | ON | OFF | OFF | ON | ON | OFF | ON |
| 312 = | ON | ON | ON | OFF | OFF | OFF | ON | ON | OFF | ON |
| 313 = | OFF | ON | ON | OFF | OFF | OFF | ON | ON | OFF | ON |
| 314 = | ON | OFF | ON | OFF | OFF | OFF | ON | ON | OFF | ON |

Table 7, Ametek Speedometer Calibration Codes, 278 to 314

| Ametek Speedometer Calibration Codes, 315 to 351 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 315 = | OFF | OFF | ON | OFF | OFF | OFF | ON | ON | OFF | ON |
| 316 = | ON | ON | OFF | OFF | OFF | OFF | ON | ON | OFF | ON |
| 317 = | OFF | ON | OFF | OFF | OFF | OFF | ON | ON | OFF | ON |
| 318 = | ON | OFF | OFF | OFF | OFF | OFF | ON | ON | OFF | ON |
| 319 = | OFF | OFF | OFF | OFF | OFF | OFF | ON | ON | OFF | ON |
| 320 = | ON | ON | ON | ON | ON | ON | OFF | ON | OFF | ON |

| Ametek Speedometer Calibration Codes, 315 to 351 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|----|-----|----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 321 = | OFF | ON | ON | ON | ON | ON | OFF | ON | OFF | ON |
| 322 = | ON | OFF | ON | ON | ON | ON | OFF | ON | OFF | ON |
| 323 = | OFF | OFF | ON | ON | ON | ON | OFF | ON | OFF | ON |
| 324 = | ON | ON | OFF | ON | ON | ON | OFF | ON | OFF | ON |
| 325 = | OFF | ON | OFF | ON | ON | ON | OFF | ON | OFF | ON |
| 326 = | ON | OFF | OFF | ON | ON | ON | OFF | ON | OFF | ON |
| 327 = | OFF | OFF | OFF | ON | ON | ON | OFF | ON | OFF | ON |
| 328 = | ON | ON | ON | OFF | ON | ON | OFF | ON | OFF | ON |
| 329 = | OFF | ON | ON | OFF | ON | ON | OFF | ON | OFF | ON |
| 330 = | ON | OFF | ON | OFF | ON | ON | OFF | ON | OFF | ON |
| 331 = | OFF | OFF | ON | OFF | ON | ON | OFF | ON | OFF | ON |
| 332 = | ON | ON | OFF | OFF | ON | ON | OFF | ON | OFF | ON |
| 333 = | OFF | ON | OFF | OFF | ON | ON | OFF | ON | OFF | ON |
| 334 = | ON | OFF | OFF | OFF | ON | ON | OFF | ON | OFF | ON |
| 335 = | OFF | OFF | OFF | OFF | ON | ON | OFF | ON | OFF | ON |
| 336 = | ON | ON | ON | ON | OFF | ON | OFF | ON | OFF | ON |
| 337 = | OFF | ON | ON | ON | OFF | ON | OFF | ON | OFF | ON |
| 338 = | ON | OFF | ON | ON | OFF | ON | OFF | ON | OFF | ON |
| 339 = | OFF | OFF | ON | ON | OFF | ON | OFF | ON | OFF | ON |
| 340 = | ON | ON | OFF | ON | OFF | ON | OFF | ON | OFF | ON |
| 341 = | OFF | ON | OFF | ON | OFF | ON | OFF | ON | OFF | ON |
| 342 = | ON | OFF | OFF | ON | OFF | ON | OFF | ON | OFF | ON |
| 343 = | OFF | OFF | OFF | ON | OFF | ON | OFF | ON | OFF | ON |
| 344 = | ON | ON | ON | OFF | OFF | ON | OFF | ON | OFF | ON |
| 345 = | OFF | ON | ON | OFF | OFF | ON | OFF | ON | OFF | ON |
| 346 = | ON | OFF | ON | OFF | OFF | ON | OFF | ON | OFF | ON |
| 347 = | OFF | OFF | ON | OFF | OFF | ON | OFF | ON | OFF | ON |
| 348 = | ON | ON | OFF | OFF | OFF | ON | OFF | ON | OFF | ON |
| 349 = | OFF | ON | OFF | OFF | OFF | ON | OFF | ON | OFF | ON |
| 350 = | ON | OFF | OFF | OFF | OFF | ON | OFF | ON | OFF | ON |
| 351 = | OFF | OFF | OFF | OFF | OFF | ON | OFF | ON | OFF | ON |

Table 8, Ametek Speedometer Calibration Codes, 315 to 351

| Ametek Speedometer Calibration Codes, 352 to 388 | | | | | | | | | | |
|--|----|----|----|----|----|-----|-----|----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 352 = | ON | ON | ON | ON | ON | OFF | OFF | ON | OFF | ON |

Specifications

| Ametek Speedometer Calibration Codes, 352 to 388 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 353 = | OFF | ON | ON | ON | ON | OFF | OFF | ON | OFF | ON |
| 354 = | ON | OFF | ON | ON | ON | OFF | OFF | ON | OFF | ON |
| 355 = | OFF | OFF | ON | ON | ON | OFF | OFF | ON | OFF | ON |
| 356 = | ON | ON | OFF | ON | ON | OFF | OFF | ON | OFF | ON |
| 357 = | OFF | ON | OFF | ON | ON | OFF | OFF | ON | OFF | ON |
| 358 = | ON | OFF | OFF | ON | ON | OFF | OFF | ON | OFF | ON |
| 359 = | OFF | OFF | OFF | ON | ON | OFF | OFF | ON | OFF | ON |
| 360 = | ON | ON | ON | OFF | ON | OFF | OFF | ON | OFF | ON |
| 361 = | OFF | ON | ON | OFF | ON | OFF | OFF | ON | OFF | ON |
| 362 = | ON | OFF | ON | OFF | ON | OFF | OFF | ON | OFF | ON |
| 363 = | OFF | OFF | ON | OFF | ON | OFF | OFF | ON | OFF | ON |
| 364 = | ON | ON | OFF | OFF | ON | OFF | OFF | ON | OFF | ON |
| 365 = | OFF | ON | OFF | OFF | ON | OFF | OFF | ON | OFF | ON |
| 366 = | ON | OFF | OFF | OFF | ON | OFF | OFF | ON | OFF | ON |
| 367 = | OFF | OFF | OFF | OFF | ON | OFF | OFF | ON | OFF | ON |
| 368 = | ON | ON | ON | ON | OFF | OFF | OFF | ON | OFF | ON |
| 369 = | OFF | ON | ON | ON | OFF | OFF | OFF | ON | OFF | ON |
| 370 = | ON | OFF | ON | ON | OFF | OFF | OFF | ON | OFF | ON |
| 371 = | OFF | OFF | ON | ON | OFF | OFF | OFF | ON | OFF | ON |
| 372 = | ON | ON | OFF | ON | OFF | OFF | OFF | ON | OFF | ON |
| 373 = | OFF | ON | OFF | ON | OFF | OFF | OFF | ON | OFF | ON |
| 374 = | ON | OFF | OFF | ON | OFF | OFF | OFF | ON | OFF | ON |
| 375 = | OFF | OFF | OFF | ON | OFF | OFF | OFF | ON | OFF | ON |
| 376 = | ON | ON | ON | OFF | OFF | OFF | OFF | ON | OFF | ON |
| 377 = | OFF | ON | ON | OFF | OFF | OFF | OFF | ON | OFF | ON |
| 378 = | ON | OFF | ON | OFF | OFF | OFF | OFF | ON | OFF | ON |
| 379 = | OFF | OFF | ON | OFF | OFF | OFF | OFF | ON | OFF | ON |
| 380 = | ON | ON | OFF | OFF | OFF | OFF | OFF | ON | OFF | ON |
| 381 = | OFF | ON | OFF | OFF | OFF | OFF | OFF | ON | OFF | ON |
| 382 = | ON | OFF | OFF | OFF | OFF | OFF | OFF | ON | OFF | ON |
| 383 = | OFF | OFF | OFF | OFF | OFF | OFF | OFF | ON | OFF | ON |
| 384 = | ON | ON | ON | ON | ON | ON | ON | OFF | OFF | ON |
| 385 = | OFF | ON | ON | ON | ON | ON | ON | OFF | OFF | ON |
| 386 = | ON | OFF | ON | ON | ON | ON | ON | OFF | OFF | ON |
| 387 = | OFF | OFF | ON | ON | ON | ON | ON | OFF | OFF | ON |

| Ametek Speedometer Calibration Codes, 352 to 388 | | | | | | | | | | |
|--|----|----|-----|----|----|----|----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 388 = | ON | ON | OFF | ON | ON | ON | ON | OFF | OFF | ON |

Table 9, Ametek Speedometer Calibration Codes, 352 to 388

| Ametek Speedometer Calibration Codes, 389 to 425 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 389 = | OFF | ON | OFF | ON | ON | ON | ON | OFF | OFF | ON |
| 390 = | ON | OFF | OFF | ON | ON | ON | ON | OFF | OFF | ON |
| 391 = | OFF | OFF | OFF | ON | ON | ON | ON | OFF | OFF | ON |
| 392 = | ON | ON | ON | OFF | ON | ON | ON | OFF | OFF | ON |
| 393 = | OFF | ON | ON | OFF | ON | ON | ON | OFF | OFF | ON |
| 394 = | ON | OFF | ON | OFF | ON | ON | ON | OFF | OFF | ON |
| 395 = | OFF | OFF | ON | OFF | ON | ON | ON | OFF | OFF | ON |
| 396 = | ON | ON | OFF | OFF | ON | ON | ON | OFF | OFF | ON |
| 397 = | OFF | ON | OFF | OFF | ON | ON | ON | OFF | OFF | ON |
| 398 = | ON | OFF | OFF | OFF | ON | ON | ON | OFF | OFF | ON |
| 399 = | OFF | OFF | OFF | OFF | ON | ON | ON | OFF | OFF | ON |
| 400 = | ON | ON | ON | ON | OFF | ON | ON | OFF | OFF | ON |
| 401 = | OFF | ON | ON | ON | OFF | ON | ON | OFF | OFF | ON |
| 402 = | ON | OFF | ON | ON | OFF | ON | ON | OFF | OFF | ON |
| 403 = | OFF | OFF | ON | ON | OFF | ON | ON | OFF | OFF | ON |
| 404 = | ON | ON | OFF | ON | OFF | ON | ON | OFF | OFF | ON |
| 405 = | OFF | ON | OFF | ON | OFF | ON | ON | OFF | OFF | ON |
| 406 = | ON | OFF | OFF | ON | OFF | ON | ON | OFF | OFF | ON |
| 407 = | OFF | OFF | OFF | ON | OFF | ON | ON | OFF | OFF | ON |
| 408 = | ON | ON | ON | OFF | OFF | ON | ON | OFF | OFF | ON |
| 409 = | OFF | ON | ON | OFF | OFF | ON | ON | OFF | OFF | ON |
| 410 = | ON | OFF | ON | OFF | OFF | ON | ON | OFF | OFF | ON |
| 411 = | OFF | OFF | ON | OFF | OFF | ON | ON | OFF | OFF | ON |
| 412 = | ON | ON | OFF | OFF | OFF | ON | ON | OFF | OFF | ON |
| 413 = | OFF | ON | OFF | OFF | OFF | ON | ON | OFF | OFF | ON |
| 414 = | ON | OFF | OFF | OFF | OFF | ON | ON | OFF | OFF | ON |
| 415 = | OFF | OFF | OFF | OFF | OFF | ON | ON | OFF | OFF | ON |
| 416 = | ON | ON | ON | ON | ON | OFF | ON | OFF | OFF | ON |
| 417 = | OFF | ON | ON | ON | ON | OFF | ON | OFF | OFF | ON |
| 418 = | ON | OFF | ON | ON | ON | OFF | ON | OFF | OFF | ON |
| 419 = | OFF | OFF | ON | ON | ON | OFF | ON | OFF | OFF | ON |

Specifications

| Ametek Speedometer Calibration Codes, 389 to 425 | | | | | | | | | | |
|--|-----|-----|-----|-----|----|-----|----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 420 = | ON | ON | OFF | ON | ON | OFF | ON | OFF | OFF | ON |
| 421 = | OFF | ON | OFF | ON | ON | OFF | ON | OFF | OFF | ON |
| 422 = | ON | OFF | OFF | ON | ON | OFF | ON | OFF | OFF | ON |
| 423 = | OFF | OFF | OFF | ON | ON | OFF | ON | OFF | OFF | ON |
| 424 = | ON | ON | ON | OFF | ON | OFF | ON | OFF | OFF | ON |
| 425 = | OFF | ON | ON | OFF | ON | OFF | ON | OFF | OFF | ON |

Table 10, Ametek Speedometer Calibration Codes, 389 to 425

| Ametek Speedometer Calibration Codes, 426 to 462 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 426 = | ON | OFF | ON | OFF | ON | OFF | ON | OFF | OFF | ON |
| 427 = | OFF | OFF | ON | OFF | ON | OFF | ON | OFF | OFF | ON |
| 428 = | ON | ON | OFF | OFF | ON | OFF | ON | OFF | OFF | ON |
| 429 = | OFF | ON | OFF | OFF | ON | OFF | ON | OFF | OFF | ON |
| 430 = | ON | OFF | OFF | OFF | ON | OFF | ON | OFF | OFF | ON |
| 431 = | OFF | OFF | OFF | OFF | ON | OFF | ON | OFF | OFF | ON |
| 432 = | ON | ON | ON | ON | OFF | OFF | ON | OFF | OFF | ON |
| 433 = | OFF | ON | ON | ON | OFF | OFF | ON | OFF | OFF | ON |
| 434 = | ON | OFF | ON | ON | OFF | OFF | ON | OFF | OFF | ON |
| 435 = | OFF | OFF | ON | ON | OFF | OFF | ON | OFF | OFF | ON |
| 436 = | ON | ON | OFF | ON | OFF | OFF | ON | OFF | OFF | ON |
| 437 = | OFF | ON | OFF | ON | OFF | OFF | ON | OFF | OFF | ON |
| 438 = | ON | OFF | OFF | ON | OFF | OFF | ON | OFF | OFF | ON |
| 439 = | OFF | OFF | OFF | ON | OFF | OFF | ON | OFF | OFF | ON |
| 440 = | ON | ON | ON | OFF | OFF | OFF | ON | OFF | OFF | ON |
| 441 = | OFF | ON | ON | OFF | OFF | OFF | ON | OFF | OFF | ON |
| 442 = | ON | OFF | ON | OFF | OFF | OFF | ON | OFF | OFF | ON |
| 443 = | OFF | OFF | ON | OFF | OFF | OFF | ON | OFF | OFF | ON |
| 444 = | ON | ON | OFF | OFF | OFF | OFF | ON | OFF | OFF | ON |
| 445 = | OFF | ON | OFF | OFF | OFF | OFF | ON | OFF | OFF | ON |
| 446 = | ON | OFF | OFF | OFF | OFF | OFF | ON | OFF | OFF | ON |
| 447 = | OFF | OFF | OFF | OFF | OFF | OFF | ON | OFF | OFF | ON |
| 448 = | ON | ON | ON | ON | ON | ON | OFF | OFF | OFF | ON |
| 449 = | OFF | ON | ON | ON | ON | ON | OFF | OFF | OFF | ON |
| 450 = | ON | OFF | ON | ON | ON | ON | OFF | OFF | OFF | ON |
| 451 = | OFF | OFF | ON | ON | ON | ON | OFF | OFF | OFF | ON |

| Ametek Speedometer Calibration Codes, 426 to 462 | | | | | | | | | | |
|--|-----|-----|-----|-----|----|----|-----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 452 = | ON | ON | OFF | ON | ON | ON | OFF | OFF | OFF | ON |
| 453 = | OFF | ON | OFF | ON | ON | ON | OFF | OFF | OFF | ON |
| 454 = | ON | OFF | OFF | ON | ON | ON | OFF | OFF | OFF | ON |
| 455 = | OFF | OFF | OFF | ON | ON | ON | OFF | OFF | OFF | ON |
| 456 = | ON | ON | ON | OFF | ON | ON | OFF | OFF | OFF | ON |
| 457 = | OFF | ON | ON | OFF | ON | ON | OFF | OFF | OFF | ON |
| 458 = | ON | OFF | ON | OFF | ON | ON | OFF | OFF | OFF | ON |
| 459 = | OFF | OFF | ON | OFF | ON | ON | OFF | OFF | OFF | ON |
| 460 = | ON | ON | OFF | OFF | ON | ON | OFF | OFF | OFF | ON |
| 461 = | OFF | ON | OFF | OFF | ON | ON | OFF | OFF | OFF | ON |
| 462 = | ON | OFF | OFF | OFF | ON | ON | OFF | OFF | OFF | ON |

Table 11, Ametek Speedometer Calibration Codes, 426 to 462

| Ametek Speedometer Calibration Codes, 463 to 499 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 463 = | OFF | OFF | OFF | OFF | ON | ON | OFF | OFF | OFF | ON |
| 464 = | ON | ON | ON | ON | OFF | ON | OFF | OFF | OFF | ON |
| 465 = | OFF | ON | ON | ON | OFF | ON | OFF | OFF | OFF | ON |
| 466 = | ON | OFF | ON | ON | OFF | ON | OFF | OFF | OFF | ON |
| 467 = | OFF | OFF | ON | ON | OFF | ON | OFF | OFF | OFF | ON |
| 468 = | ON | ON | OFF | ON | OFF | ON | OFF | OFF | OFF | ON |
| 469 = | OFF | ON | OFF | ON | OFF | ON | OFF | OFF | OFF | ON |
| 470 = | ON | OFF | OFF | ON | OFF | ON | OFF | OFF | OFF | ON |
| 471 = | OFF | OFF | OFF | ON | OFF | ON | OFF | OFF | OFF | ON |
| 472 = | ON | ON | ON | OFF | OFF | ON | OFF | OFF | OFF | ON |
| 473 = | OFF | ON | ON | OFF | OFF | ON | OFF | OFF | OFF | ON |
| 474 = | ON | OFF | ON | OFF | OFF | ON | OFF | OFF | OFF | ON |
| 475 = | OFF | OFF | ON | OFF | OFF | ON | OFF | OFF | OFF | ON |
| 476 = | ON | ON | OFF | OFF | OFF | ON | OFF | OFF | OFF | ON |
| 477 = | OFF | ON | OFF | OFF | OFF | ON | OFF | OFF | OFF | ON |
| 478 = | ON | OFF | OFF | OFF | OFF | ON | OFF | OFF | OFF | ON |
| 479 = | OFF | OFF | OFF | OFF | OFF | ON | OFF | OFF | OFF | ON |
| 480 = | ON | ON | ON | ON | ON | OFF | OFF | OFF | OFF | ON |
| 481 = | OFF | ON | ON | ON | ON | OFF | OFF | OFF | OFF | ON |
| 482 = | ON | OFF | ON | ON | ON | OFF | OFF | OFF | OFF | ON |
| 483 = | OFF | OFF | ON | ON | ON | OFF | OFF | OFF | OFF | ON |

Specifications

| Ametek Speedometer Calibration Codes, 463 to 499 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 484 = | ON | ON | OFF | ON | ON | OFF | OFF | OFF | OFF | ON |
| 485 = | OFF | ON | OFF | ON | ON | OFF | OFF | OFF | OFF | ON |
| 486 = | ON | OFF | OFF | ON | ON | OFF | OFF | OFF | OFF | ON |
| 487 = | OFF | OFF | OFF | ON | ON | OFF | OFF | OFF | OFF | ON |
| 488 = | ON | ON | ON | OFF | ON | OFF | OFF | OFF | OFF | ON |
| 489 = | OFF | ON | ON | OFF | ON | OFF | OFF | OFF | OFF | ON |
| 490 = | ON | OFF | ON | OFF | ON | OFF | OFF | OFF | OFF | ON |
| 491 = | OFF | OFF | ON | OFF | ON | OFF | OFF | OFF | OFF | ON |
| 492 = | ON | ON | OFF | OFF | ON | OFF | OFF | OFF | OFF | ON |
| 493 = | OFF | ON | OFF | OFF | ON | OFF | OFF | OFF | OFF | ON |
| 494 = | ON | OFF | OFF | OFF | ON | OFF | OFF | OFF | OFF | ON |
| 495 = | OFF | OFF | OFF | OFF | ON | OFF | OFF | OFF | OFF | ON |
| 496 = | ON | ON | ON | ON | OFF | OFF | OFF | OFF | OFF | ON |
| 497 = | OFF | ON | ON | ON | OFF | OFF | OFF | OFF | OFF | ON |
| 498 = | ON | OFF | ON | ON | OFF | OFF | OFF | OFF | OFF | ON |
| 499 = | OFF | OFF | ON | ON | OFF | OFF | OFF | OFF | OFF | ON |

Table 12, Ametek Speedometer Calibration Codes, 463 to 499

| Ametek Speedometer Calibration Codes, 500 to 536 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 500 = | ON | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF | ON |
| 501 = | OFF | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF | ON |
| 502 = | ON | OFF | OFF | ON | OFF | OFF | OFF | OFF | OFF | ON |
| 503 = | OFF | OFF | OFF | ON | OFF | OFF | OFF | OFF | OFF | ON |
| 504 = | ON | ON | ON | OFF | OFF | OFF | OFF | OFF | OFF | ON |
| 505 = | OFF | ON | ON | OFF | OFF | OFF | OFF | OFF | OFF | ON |
| 506 = | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF | ON |
| 507 = | OFF | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF | ON |
| 508 = | ON | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF | ON |
| 509 = | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF | ON |
| 510 = | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF | ON |
| 511 = | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF | ON |
| 512 = | ON | ON | ON | ON | ON | ON | ON | ON | ON | OFF |
| 513 = | OFF | ON | ON | ON | ON | ON | ON | ON | ON | OFF |
| 514 = | ON | OFF | ON | ON | ON | ON | ON | ON | ON | OFF |
| 515 = | OFF | OFF | ON | ON | ON | ON | ON | ON | ON | OFF |

| Ametek Speedometer Calibration Codes, 500 to 536 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|----|----|----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 516 = | ON | ON | OFF | ON | ON | ON | ON | ON | ON | OFF |
| 517 = | OFF | ON | OFF | ON | ON | ON | ON | ON | ON | OFF |
| 518 = | ON | OFF | OFF | ON | ON | ON | ON | ON | ON | OFF |
| 519 = | OFF | OFF | OFF | ON | ON | ON | ON | ON | ON | OFF |
| 520 = | ON | ON | ON | OFF | ON | ON | ON | ON | ON | OFF |
| 521 = | OFF | ON | ON | OFF | ON | ON | ON | ON | ON | OFF |
| 522 = | ON | OFF | ON | OFF | ON | ON | ON | ON | ON | OFF |
| 523 = | OFF | OFF | ON | OFF | ON | ON | ON | ON | ON | OFF |
| 524 = | ON | ON | OFF | OFF | ON | ON | ON | ON | ON | OFF |
| 525 = | OFF | ON | OFF | OFF | ON | ON | ON | ON | ON | OFF |
| 526 = | ON | OFF | OFF | OFF | ON | ON | ON | ON | ON | OFF |
| 527 = | OFF | OFF | OFF | OFF | ON | ON | ON | ON | ON | OFF |
| 528 = | ON | ON | ON | ON | OFF | ON | ON | ON | ON | OFF |
| 529 = | OFF | ON | ON | ON | OFF | ON | ON | ON | ON | OFF |
| 530 = | ON | OFF | ON | ON | OFF | ON | ON | ON | ON | OFF |
| 531 = | OFF | OFF | ON | ON | OFF | ON | ON | ON | ON | OFF |
| 532 = | ON | ON | OFF | ON | OFF | ON | ON | ON | ON | OFF |
| 533 = | OFF | ON | OFF | ON | OFF | ON | ON | ON | ON | OFF |
| 534 = | ON | OFF | OFF | ON | OFF | ON | ON | ON | ON | OFF |
| 535 = | OFF | OFF | OFF | ON | OFF | ON | ON | ON | ON | OFF |
| 536 = | ON | ON | ON | OFF | OFF | ON | ON | ON | ON | OFF |

Table 13, Ametek Speedometer Calibration Codes, 500 to 536

| Ametek Speedometer Calibration Codes, 537 to 573 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|----|----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 537 = | OFF | ON | ON | OFF | OFF | ON | ON | ON | ON | OFF |
| 538 = | ON | OFF | ON | OFF | OFF | ON | ON | ON | ON | OFF |
| 539 = | OFF | OFF | ON | OFF | OFF | ON | ON | ON | ON | OFF |
| 540 = | ON | ON | OFF | OFF | OFF | ON | ON | ON | ON | OFF |
| 541 = | OFF | ON | OFF | OFF | OFF | ON | ON | ON | ON | OFF |
| 542 = | ON | OFF | OFF | OFF | OFF | ON | ON | ON | ON | OFF |
| 543 = | OFF | OFF | OFF | OFF | OFF | ON | ON | ON | ON | OFF |
| 544 = | ON | ON | ON | ON | ON | OFF | ON | ON | ON | OFF |
| 545 = | OFF | ON | ON | ON | ON | OFF | ON | ON | ON | OFF |
| 546 = | ON | OFF | ON | ON | ON | OFF | ON | ON | ON | OFF |
| 547 = | OFF | OFF | ON | ON | ON | OFF | ON | ON | ON | OFF |

Specifications

| Ametek Speedometer Calibration Codes, 537 to 573 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|----|----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 548 = | ON | ON | OFF | ON | ON | OFF | ON | ON | ON | OFF |
| 549 = | OFF | ON | OFF | ON | ON | OFF | ON | ON | ON | OFF |
| 550 = | ON | OFF | OFF | ON | ON | OFF | ON | ON | ON | OFF |
| 551 = | OFF | OFF | OFF | ON | ON | OFF | ON | ON | ON | OFF |
| 552 = | ON | ON | ON | OFF | ON | OFF | ON | ON | ON | OFF |
| 553 = | OFF | ON | ON | OFF | ON | OFF | ON | ON | ON | OFF |
| 554 = | ON | OFF | ON | OFF | ON | OFF | ON | ON | ON | OFF |
| 555 = | OFF | OFF | ON | OFF | ON | OFF | ON | ON | ON | OFF |
| 556 = | ON | ON | OFF | OFF | ON | OFF | ON | ON | ON | OFF |
| 557 = | OFF | ON | OFF | OFF | ON | OFF | ON | ON | ON | OFF |
| 558 = | ON | OFF | OFF | OFF | ON | OFF | ON | ON | ON | OFF |
| 559 = | OFF | OFF | OFF | OFF | ON | OFF | ON | ON | ON | OFF |
| 560 = | ON | ON | ON | ON | OFF | OFF | ON | ON | ON | OFF |
| 561 = | OFF | ON | ON | ON | OFF | OFF | ON | ON | ON | OFF |
| 562 = | ON | OFF | ON | ON | OFF | OFF | ON | ON | ON | OFF |
| 563 = | OFF | OFF | ON | ON | OFF | OFF | ON | ON | ON | OFF |
| 564 = | ON | ON | OFF | ON | OFF | OFF | ON | ON | ON | OFF |
| 565 = | OFF | ON | OFF | ON | OFF | OFF | ON | ON | ON | OFF |
| 566 = | ON | OFF | OFF | ON | OFF | OFF | ON | ON | ON | OFF |
| 567 = | OFF | OFF | OFF | ON | OFF | OFF | ON | ON | ON | OFF |
| 568 = | ON | ON | ON | OFF | OFF | OFF | ON | ON | ON | OFF |
| 569 = | OFF | ON | ON | OFF | OFF | OFF | ON | ON | ON | OFF |
| 570 = | ON | OFF | ON | OFF | OFF | OFF | ON | ON | ON | OFF |
| 571 = | OFF | OFF | ON | OFF | OFF | OFF | ON | ON | ON | OFF |
| 572 = | ON | ON | OFF | OFF | OFF | OFF | ON | ON | ON | OFF |
| 573 = | OFF | ON | OFF | OFF | OFF | OFF | ON | ON | ON | OFF |

Table 14, Ametek Speedometer Calibration Codes, 537 to 573

| Ametek Speedometer Calibration Codes, 574 to 610 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 574 = | ON | OFF | OFF | OFF | OFF | OFF | ON | ON | ON | OFF |
| 575 = | OFF | OFF | OFF | OFF | OFF | OFF | ON | ON | ON | OFF |
| 576 = | ON | ON | ON | ON | ON | ON | OFF | ON | ON | OFF |
| 577 = | OFF | ON | ON | ON | ON | ON | OFF | ON | ON | OFF |
| 578 = | ON | OFF | ON | ON | ON | ON | OFF | ON | ON | OFF |
| 579 = | OFF | OFF | ON | ON | ON | ON | OFF | ON | ON | OFF |

| Ametek Speedometer Calibration Codes, 574 to 610 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 580 = | ON | ON | OFF | ON | ON | ON | OFF | ON | ON | OFF |
| 581 = | OFF | ON | OFF | ON | ON | ON | OFF | ON | ON | OFF |
| 582 = | ON | OFF | OFF | ON | ON | ON | OFF | ON | ON | OFF |
| 583 = | OFF | OFF | OFF | ON | ON | ON | OFF | ON | ON | OFF |
| 584 = | ON | ON | ON | OFF | ON | ON | OFF | ON | ON | OFF |
| 585 = | OFF | ON | ON | OFF | ON | ON | OFF | ON | ON | OFF |
| 586 = | ON | OFF | ON | OFF | ON | ON | OFF | ON | ON | OFF |
| 587 = | OFF | OFF | ON | OFF | ON | ON | OFF | ON | ON | OFF |
| 588 = | ON | ON | OFF | OFF | ON | ON | OFF | ON | ON | OFF |
| 589 = | OFF | ON | OFF | OFF | ON | ON | OFF | ON | ON | OFF |
| 590 = | ON | OFF | OFF | OFF | ON | ON | OFF | ON | ON | OFF |
| 591 = | OFF | OFF | OFF | OFF | ON | ON | OFF | ON | ON | OFF |
| 592 = | ON | ON | ON | ON | OFF | ON | OFF | ON | ON | OFF |
| 593 = | OFF | ON | ON | ON | OFF | ON | OFF | ON | ON | OFF |
| 594 = | ON | OFF | ON | ON | OFF | ON | OFF | ON | ON | OFF |
| 595 = | OFF | OFF | ON | ON | OFF | ON | OFF | ON | ON | OFF |
| 596 = | ON | ON | OFF | ON | OFF | ON | OFF | ON | ON | OFF |
| 597 = | OFF | ON | OFF | ON | OFF | ON | OFF | ON | ON | OFF |
| 598 = | ON | OFF | OFF | ON | OFF | ON | OFF | ON | ON | OFF |
| 599 = | OFF | OFF | OFF | ON | OFF | ON | OFF | ON | ON | OFF |
| 600 = | ON | ON | ON | OFF | OFF | ON | OFF | ON | ON | OFF |
| 601 = | OFF | ON | ON | OFF | OFF | ON | OFF | ON | ON | OFF |
| 602 = | ON | OFF | ON | OFF | OFF | ON | OFF | ON | ON | OFF |
| 603 = | OFF | OFF | ON | OFF | OFF | ON | OFF | ON | ON | OFF |
| 604 = | ON | ON | OFF | OFF | OFF | ON | OFF | ON | ON | OFF |
| 605 = | OFF | ON | OFF | OFF | OFF | ON | OFF | ON | ON | OFF |
| 606 = | ON | OFF | OFF | OFF | OFF | ON | OFF | ON | ON | OFF |
| 607 = | OFF | OFF | OFF | OFF | OFF | ON | OFF | ON | ON | OFF |
| 608 = | ON | ON | ON | ON | ON | OFF | OFF | ON | ON | OFF |
| 609 = | OFF | ON | ON | ON | ON | OFF | OFF | ON | ON | OFF |
| 610 = | ON | OFF | ON | ON | ON | OFF | OFF | ON | ON | OFF |

Table 15, Ametek Speedometer Calibration Codes, 574 to 610

| Ametek Speedometer Calibration Codes, 611 to 647 | | | | | | | | | | |
|--|-----|-----|----|----|----|-----|-----|----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 611 = | OFF | OFF | ON | ON | ON | OFF | OFF | ON | ON | OFF |

Specifications

| Ametek Speedometer Calibration Codes, 611 to 647 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 612 = | ON | ON | OFF | ON | ON | OFF | OFF | ON | ON | OFF |
| 613 = | OFF | ON | OFF | ON | ON | OFF | OFF | ON | ON | OFF |
| 614 = | ON | OFF | OFF | ON | ON | OFF | OFF | ON | ON | OFF |
| 615 = | OFF | OFF | OFF | ON | ON | OFF | OFF | ON | ON | OFF |
| 616 = | ON | ON | ON | OFF | ON | OFF | OFF | ON | ON | OFF |
| 617 = | OFF | ON | ON | OFF | ON | OFF | OFF | ON | ON | OFF |
| 618 = | ON | OFF | ON | OFF | ON | OFF | OFF | ON | ON | OFF |
| 619 = | OFF | OFF | ON | OFF | ON | OFF | OFF | ON | ON | OFF |
| 620 = | ON | ON | OFF | OFF | ON | OFF | OFF | ON | ON | OFF |
| 621 = | OFF | ON | OFF | OFF | ON | OFF | OFF | ON | ON | OFF |
| 622 = | ON | OFF | OFF | OFF | ON | OFF | OFF | ON | ON | OFF |
| 623 = | OFF | OFF | OFF | OFF | ON | OFF | OFF | ON | ON | OFF |
| 624 = | ON | ON | ON | ON | OFF | OFF | OFF | ON | ON | OFF |
| 625 = | OFF | ON | ON | ON | OFF | OFF | OFF | ON | ON | OFF |
| 626 = | ON | OFF | ON | ON | OFF | OFF | OFF | ON | ON | OFF |
| 627 = | OFF | OFF | ON | ON | OFF | OFF | OFF | ON | ON | OFF |
| 628 = | ON | ON | OFF | ON | OFF | OFF | OFF | ON | ON | OFF |
| 629 = | OFF | ON | OFF | ON | OFF | OFF | OFF | ON | ON | OFF |
| 630 = | ON | OFF | OFF | ON | OFF | OFF | OFF | ON | ON | OFF |
| 631 = | OFF | OFF | OFF | ON | OFF | OFF | OFF | ON | ON | OFF |
| 632 = | ON | ON | ON | OFF | OFF | OFF | OFF | ON | ON | OFF |
| 633 = | OFF | ON | ON | OFF | OFF | OFF | OFF | ON | ON | OFF |
| 634 = | ON | OFF | ON | OFF | OFF | OFF | OFF | ON | ON | OFF |
| 635 = | OFF | OFF | ON | OFF | OFF | OFF | OFF | ON | ON | OFF |
| 636 = | ON | ON | OFF | OFF | OFF | OFF | OFF | ON | ON | OFF |
| 637 = | OFF | ON | OFF | OFF | OFF | OFF | OFF | ON | ON | OFF |
| 638 = | ON | OFF | OFF | OFF | OFF | OFF | OFF | ON | ON | OFF |
| 639 = | OFF | OFF | OFF | OFF | OFF | OFF | OFF | ON | ON | OFF |
| 640 = | ON | ON | ON | ON | ON | ON | ON | OFF | ON | OFF |
| 641 = | OFF | ON | ON | ON | ON | ON | ON | OFF | ON | OFF |
| 642 = | ON | OFF | ON | ON | ON | ON | ON | OFF | ON | OFF |
| 643 = | OFF | OFF | ON | ON | ON | ON | ON | OFF | ON | OFF |
| 644 = | ON | ON | OFF | ON | ON | ON | ON | OFF | ON | OFF |
| 645 = | OFF | ON | OFF | ON | ON | ON | ON | OFF | ON | OFF |
| 646 = | ON | OFF | OFF | ON | ON | ON | ON | OFF | ON | OFF |

| Ametek Speedometer Calibration Codes, 611 to 647 | | | | | | | | | | |
|--|-----|-----|-----|----|----|----|----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 647 = | OFF | OFF | OFF | ON | ON | ON | ON | OFF | ON | OFF |

Table 16, Ametek Speedometer Calibration Codes, 611 to 647

| Ametek Speedometer Calibration Codes, 648 to 684 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 648 = | ON | ON | ON | OFF | ON | ON | ON | OFF | ON | OFF |
| 649 = | OFF | ON | ON | OFF | ON | ON | ON | OFF | ON | OFF |
| 650 = | ON | OFF | ON | OFF | ON | ON | ON | OFF | ON | OFF |
| 651 = | OFF | OFF | ON | OFF | ON | ON | ON | OFF | ON | OFF |
| 652 = | ON | ON | OFF | OFF | ON | ON | ON | OFF | ON | OFF |
| 653 = | OFF | ON | OFF | OFF | ON | ON | ON | OFF | ON | OFF |
| 654 = | ON | OFF | OFF | OFF | ON | ON | ON | OFF | ON | OFF |
| 655 = | OFF | OFF | OFF | OFF | ON | ON | ON | OFF | ON | OFF |
| 656 = | ON | ON | ON | ON | OFF | ON | ON | OFF | ON | OFF |
| 657 = | OFF | ON | ON | ON | OFF | ON | ON | OFF | ON | OFF |
| 658 = | ON | OFF | ON | ON | OFF | ON | ON | OFF | ON | OFF |
| 659 = | OFF | OFF | ON | ON | OFF | ON | ON | OFF | ON | OFF |
| 660 = | ON | ON | OFF | ON | OFF | ON | ON | OFF | ON | OFF |
| 661 = | OFF | ON | OFF | ON | OFF | ON | ON | OFF | ON | OFF |
| 662 = | ON | OFF | OFF | ON | OFF | ON | ON | OFF | ON | OFF |
| 663 = | OFF | OFF | OFF | ON | OFF | ON | ON | OFF | ON | OFF |
| 664 = | ON | ON | ON | OFF | OFF | ON | ON | OFF | ON | OFF |
| 665 = | OFF | ON | ON | OFF | OFF | ON | ON | OFF | ON | OFF |
| 666 = | ON | OFF | ON | OFF | OFF | ON | ON | OFF | ON | OFF |
| 667 = | OFF | OFF | ON | OFF | OFF | ON | ON | OFF | ON | OFF |
| 668 = | ON | ON | OFF | OFF | OFF | ON | ON | OFF | ON | OFF |
| 669 = | OFF | ON | OFF | OFF | OFF | ON | ON | OFF | ON | OFF |
| 670 = | ON | OFF | OFF | OFF | OFF | ON | ON | OFF | ON | OFF |
| 671 = | OFF | OFF | OFF | OFF | OFF | ON | ON | OFF | ON | OFF |
| 672 = | ON | ON | ON | ON | ON | OFF | ON | OFF | ON | OFF |
| 673 = | OFF | ON | ON | ON | ON | OFF | ON | OFF | ON | OFF |
| 674 = | ON | OFF | ON | ON | ON | OFF | ON | OFF | ON | OFF |
| 675 = | OFF | OFF | ON | ON | ON | OFF | ON | OFF | ON | OFF |
| 676 = | ON | ON | OFF | ON | ON | OFF | ON | OFF | ON | OFF |
| 677 = | OFF | ON | OFF | ON | ON | OFF | ON | OFF | ON | OFF |
| 678 = | ON | OFF | OFF | ON | ON | OFF | ON | OFF | ON | OFF |

Specifications

| Ametek Speedometer Calibration Codes, 648 to 684 | | | | | | | | | | |
|--|-----|-----|-----|-----|----|-----|----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 679 = | OFF | OFF | OFF | ON | ON | OFF | ON | OFF | ON | OFF |
| 680 = | ON | ON | ON | OFF | ON | OFF | ON | OFF | ON | OFF |
| 681 = | OFF | ON | ON | OFF | ON | OFF | ON | OFF | ON | OFF |
| 682 = | ON | OFF | ON | OFF | ON | OFF | ON | OFF | ON | OFF |
| 683 = | OFF | OFF | ON | OFF | ON | OFF | ON | OFF | ON | OFF |
| 684 = | ON | ON | OFF | OFF | ON | OFF | ON | OFF | ON | OFF |

Table 17, Ametek Speedometer Calibration Codes, 648 to 684

| Ametek Speedometer Calibration Codes, 685 to 721 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 685 = | OFF | ON | OFF | OFF | ON | OFF | ON | OFF | ON | OFF |
| 686 = | ON | OFF | OFF | OFF | ON | OFF | ON | OFF | ON | OFF |
| 687 = | OFF | OFF | OFF | OFF | ON | OFF | ON | OFF | ON | OFF |
| 688 = | ON | ON | ON | ON | OFF | OFF | ON | OFF | ON | OFF |
| 689 = | OFF | ON | ON | ON | OFF | OFF | ON | OFF | ON | OFF |
| 690 = | ON | OFF | ON | ON | OFF | OFF | ON | OFF | ON | OFF |
| 691 = | OFF | OFF | ON | ON | OFF | OFF | ON | OFF | ON | OFF |
| 692 = | ON | ON | OFF | ON | OFF | OFF | ON | OFF | ON | OFF |
| 693 = | OFF | ON | OFF | ON | OFF | OFF | ON | OFF | ON | OFF |
| 694 = | ON | OFF | OFF | ON | OFF | OFF | ON | OFF | ON | OFF |
| 695 = | OFF | OFF | OFF | ON | OFF | OFF | ON | OFF | ON | OFF |
| 696 = | ON | ON | ON | OFF | OFF | OFF | ON | OFF | ON | OFF |
| 697 = | OFF | ON | ON | OFF | OFF | OFF | ON | OFF | ON | OFF |
| 698 = | ON | OFF | ON | OFF | OFF | OFF | ON | OFF | ON | OFF |
| 699 = | OFF | OFF | ON | OFF | OFF | OFF | ON | OFF | ON | OFF |
| 700 = | ON | ON | OFF | OFF | OFF | OFF | ON | OFF | ON | OFF |
| 701 = | OFF | ON | OFF | OFF | OFF | OFF | ON | OFF | ON | OFF |
| 702 = | ON | OFF | OFF | OFF | OFF | OFF | ON | OFF | ON | OFF |
| 703 = | OFF | OFF | OFF | OFF | OFF | OFF | ON | OFF | ON | OFF |
| 704 = | ON | ON | ON | ON | ON | ON | OFF | OFF | ON | OFF |
| 705 = | OFF | ON | ON | ON | ON | ON | OFF | OFF | ON | OFF |
| 706 = | ON | OFF | ON | ON | ON | ON | OFF | OFF | ON | OFF |
| 707 = | OFF | OFF | ON | ON | ON | ON | OFF | OFF | ON | OFF |
| 708 = | ON | ON | OFF | ON | ON | ON | OFF | OFF | ON | OFF |
| 709 = | OFF | ON | OFF | ON | ON | ON | OFF | OFF | ON | OFF |
| 710 = | ON | OFF | OFF | ON | ON | ON | OFF | OFF | ON | OFF |

| Ametek Speedometer Calibration Codes, 685 to 721 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|----|-----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 711 = | OFF | OFF | OFF | ON | ON | ON | OFF | OFF | ON | OFF |
| 712 = | ON | ON | ON | OFF | ON | ON | OFF | OFF | ON | OFF |
| 713 = | OFF | ON | ON | OFF | ON | ON | OFF | OFF | ON | OFF |
| 714 = | ON | OFF | ON | OFF | ON | ON | OFF | OFF | ON | OFF |
| 715 = | OFF | OFF | ON | OFF | ON | ON | OFF | OFF | ON | OFF |
| 716 = | ON | ON | OFF | OFF | ON | ON | OFF | OFF | ON | OFF |
| 717 = | OFF | ON | OFF | OFF | ON | ON | OFF | OFF | ON | OFF |
| 718 = | ON | OFF | OFF | OFF | ON | ON | OFF | OFF | ON | OFF |
| 719 = | OFF | OFF | OFF | OFF | ON | ON | OFF | OFF | ON | OFF |
| 720 = | ON | ON | ON | ON | OFF | ON | OFF | OFF | ON | OFF |
| 721 = | OFF | ON | ON | ON | OFF | ON | OFF | OFF | ON | OFF |

Table 18, Ametek Speedometer Calibration Codes, 685 to 721

| Ametek Speedometer Calibration Codes, 722 to 758 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 722 = | ON | OFF | ON | ON | OFF | ON | OFF | OFF | ON | OFF |
| 723 = | OFF | OFF | ON | ON | OFF | ON | OFF | OFF | ON | OFF |
| 724 = | ON | ON | OFF | ON | OFF | ON | OFF | OFF | ON | OFF |
| 725 = | OFF | ON | OFF | ON | OFF | ON | OFF | OFF | ON | OFF |
| 726 = | ON | OFF | OFF | ON | OFF | ON | OFF | OFF | ON | OFF |
| 727 = | OFF | OFF | OFF | ON | OFF | ON | OFF | OFF | ON | OFF |
| 728 = | ON | ON | ON | OFF | OFF | ON | OFF | OFF | ON | OFF |
| 729 = | OFF | ON | ON | OFF | OFF | ON | OFF | OFF | ON | OFF |
| 730 = | ON | OFF | ON | OFF | OFF | ON | OFF | OFF | ON | OFF |
| 731 = | OFF | OFF | ON | OFF | OFF | ON | OFF | OFF | ON | OFF |
| 732 = | ON | ON | OFF | OFF | OFF | ON | OFF | OFF | ON | OFF |
| 733 = | OFF | ON | OFF | OFF | OFF | ON | OFF | OFF | ON | OFF |
| 734 = | ON | OFF | OFF | OFF | OFF | ON | OFF | OFF | ON | OFF |
| 735 = | OFF | OFF | OFF | OFF | OFF | ON | OFF | OFF | ON | OFF |
| 736 = | ON | ON | ON | ON | ON | OFF | OFF | OFF | ON | OFF |
| 737 = | OFF | ON | ON | ON | ON | OFF | OFF | OFF | ON | OFF |
| 738 = | ON | OFF | ON | ON | ON | OFF | OFF | OFF | ON | OFF |
| 739 = | OFF | OFF | ON | ON | ON | OFF | OFF | OFF | ON | OFF |
| 740 = | ON | ON | OFF | ON | ON | OFF | OFF | OFF | ON | OFF |
| 741 = | OFF | ON | OFF | ON | ON | OFF | OFF | OFF | ON | OFF |
| 742 = | ON | OFF | OFF | ON | ON | OFF | OFF | OFF | ON | OFF |

Specifications

| Ametek Speedometer Calibration Codes, 722 to 758 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 743 = | OFF | OFF | OFF | ON | ON | OFF | OFF | OFF | ON | OFF |
| 744 = | ON | ON | ON | OFF | ON | OFF | OFF | OFF | ON | OFF |
| 745 = | OFF | ON | ON | OFF | ON | OFF | OFF | OFF | ON | OFF |
| 746 = | ON | OFF | ON | OFF | ON | OFF | OFF | OFF | ON | OFF |
| 747 = | OFF | OFF | ON | OFF | ON | OFF | OFF | OFF | ON | OFF |
| 748 = | ON | ON | OFF | OFF | ON | OFF | OFF | OFF | ON | OFF |
| 749 = | OFF | ON | OFF | OFF | ON | OFF | OFF | OFF | ON | OFF |
| 750 = | ON | OFF | OFF | OFF | ON | OFF | OFF | OFF | ON | OFF |
| 751 = | OFF | OFF | OFF | OFF | ON | OFF | OFF | OFF | ON | OFF |
| 752 = | ON | ON | ON | ON | OFF | OFF | OFF | OFF | ON | OFF |
| 753 = | OFF | ON | ON | ON | OFF | OFF | OFF | OFF | ON | OFF |
| 754 = | ON | OFF | ON | ON | OFF | OFF | OFF | OFF | ON | OFF |
| 755 = | OFF | OFF | ON | ON | OFF | OFF | OFF | OFF | ON | OFF |
| 756 = | ON | ON | OFF | ON | OFF | OFF | OFF | OFF | ON | OFF |
| 757 = | OFF | ON | OFF | ON | OFF | OFF | OFF | OFF | ON | OFF |
| 758 = | ON | OFF | OFF | ON | OFF | OFF | OFF | OFF | ON | OFF |

Table 19, Ametek Speedometer Calibration Codes, 722 to 758

| Ametek Speedometer Calibration Codes, 759 to 795 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 759 = | OFF | OFF | OFF | ON | OFF | OFF | OFF | OFF | ON | OFF |
| 760 = | ON | ON | ON | OFF | OFF | OFF | OFF | OFF | ON | OFF |
| 761 = | OFF | ON | ON | OFF | OFF | OFF | OFF | OFF | ON | OFF |
| 762 = | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF | ON | OFF |
| 763 = | OFF | OFF | ON | OFF | OFF | OFF | OFF | OFF | ON | OFF |
| 764 = | ON | ON | OFF | OFF | OFF | OFF | OFF | OFF | ON | OFF |
| 765 = | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF | ON | OFF |
| 766 = | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF | ON | OFF |
| 767 = | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF | ON | OFF |
| 768 = | ON | ON | ON | ON | ON | ON | ON | ON | OFF | OFF |
| 769 = | OFF | ON | ON | ON | ON | ON | ON | ON | OFF | OFF |
| 770 = | ON | OFF | ON | ON | ON | ON | ON | ON | OFF | OFF |
| 771 = | OFF | OFF | ON | ON | ON | ON | ON | ON | OFF | OFF |
| 772 = | ON | ON | OFF | ON | ON | ON | ON | ON | OFF | OFF |
| 773 = | OFF | ON | OFF | ON | ON | ON | ON | ON | OFF | OFF |
| 774 = | ON | OFF | OFF | ON | ON | ON | ON | ON | OFF | OFF |

| Ametek Speedometer Calibration Codes, 759 to 795 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|----|----|----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 775 = | OFF | OFF | OFF | ON | ON | ON | ON | ON | OFF | OFF |
| 776 = | ON | ON | ON | OFF | ON | ON | ON | ON | OFF | OFF |
| 777 = | OFF | ON | ON | OFF | ON | ON | ON | ON | OFF | OFF |
| 778 = | ON | OFF | ON | OFF | ON | ON | ON | ON | OFF | OFF |
| 779 = | OFF | OFF | ON | OFF | ON | ON | ON | ON | OFF | OFF |
| 780 = | ON | ON | OFF | OFF | ON | ON | ON | ON | OFF | OFF |
| 781 = | OFF | ON | OFF | OFF | ON | ON | ON | ON | OFF | OFF |
| 782 = | ON | OFF | OFF | OFF | ON | ON | ON | ON | OFF | OFF |
| 783 = | OFF | OFF | OFF | OFF | ON | ON | ON | ON | OFF | OFF |
| 784 = | ON | ON | ON | ON | OFF | ON | ON | ON | OFF | OFF |
| 785 = | OFF | ON | ON | ON | OFF | ON | ON | ON | OFF | OFF |
| 786 = | ON | OFF | ON | ON | OFF | ON | ON | ON | OFF | OFF |
| 787 = | OFF | OFF | ON | ON | OFF | ON | ON | ON | OFF | OFF |
| 788 = | ON | ON | OFF | ON | OFF | ON | ON | ON | OFF | OFF |
| 789 = | OFF | ON | OFF | ON | OFF | ON | ON | ON | OFF | OFF |
| 790 = | ON | OFF | OFF | ON | OFF | ON | ON | ON | OFF | OFF |
| 791 = | OFF | OFF | OFF | ON | OFF | ON | ON | ON | OFF | OFF |
| 792 = | ON | ON | ON | OFF | OFF | ON | ON | ON | OFF | OFF |
| 793 = | OFF | ON | ON | OFF | OFF | ON | ON | ON | OFF | OFF |
| 794 = | ON | OFF | ON | OFF | OFF | ON | ON | ON | OFF | OFF |
| 795 = | OFF | OFF | ON | OFF | OFF | ON | ON | ON | OFF | OFF |

Table 20, Ametek Speedometer Calibration Codes, 759 to 795

| Ametek Speedometer Calibration Codes, 796 to 832 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|----|----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 796 = | ON | ON | OFF | OFF | OFF | ON | ON | ON | OFF | OFF |
| 797 = | OFF | ON | OFF | OFF | OFF | ON | ON | ON | OFF | OFF |
| 798 = | ON | OFF | OFF | OFF | OFF | ON | ON | ON | OFF | OFF |
| 799 = | OFF | OFF | OFF | OFF | OFF | ON | ON | ON | OFF | OFF |
| 800 = | ON | ON | ON | ON | ON | OFF | ON | ON | OFF | OFF |
| 801 = | OFF | ON | ON | ON | ON | OFF | ON | ON | OFF | OFF |
| 802 = | ON | OFF | ON | ON | ON | OFF | ON | ON | OFF | OFF |
| 803 = | OFF | OFF | ON | ON | ON | OFF | ON | ON | OFF | OFF |
| 804 = | ON | ON | OFF | ON | ON | OFF | ON | ON | OFF | OFF |
| 805 = | OFF | ON | OFF | ON | ON | OFF | ON | ON | OFF | OFF |
| 806 = | ON | OFF | OFF | ON | ON | OFF | ON | ON | OFF | OFF |

Specifications

| Ametek Speedometer Calibration Codes, 796 to 832 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 807 = | OFF | OFF | OFF | ON | ON | OFF | ON | ON | OFF | OFF |
| 808 = | ON | ON | ON | OFF | ON | OFF | ON | ON | OFF | OFF |
| 809 = | OFF | ON | ON | OFF | ON | OFF | ON | ON | OFF | OFF |
| 810 = | ON | OFF | ON | OFF | ON | OFF | ON | ON | OFF | OFF |
| 811 = | OFF | OFF | ON | OFF | ON | OFF | ON | ON | OFF | OFF |
| 812 = | ON | ON | OFF | OFF | ON | OFF | ON | ON | OFF | OFF |
| 813 = | OFF | ON | OFF | OFF | ON | OFF | ON | ON | OFF | OFF |
| 814 = | ON | OFF | OFF | OFF | ON | OFF | ON | ON | OFF | OFF |
| 815 = | OFF | OFF | OFF | OFF | ON | OFF | ON | ON | OFF | OFF |
| 816 = | ON | ON | ON | ON | OFF | OFF | ON | ON | OFF | OFF |
| 817 = | OFF | ON | ON | ON | OFF | OFF | ON | ON | OFF | OFF |
| 818 = | ON | OFF | ON | ON | OFF | OFF | ON | ON | OFF | OFF |
| 819 = | OFF | OFF | ON | ON | OFF | OFF | ON | ON | OFF | OFF |
| 820 = | ON | ON | OFF | ON | OFF | OFF | ON | ON | OFF | OFF |
| 821 = | OFF | ON | OFF | ON | OFF | OFF | ON | ON | OFF | OFF |
| 822 = | ON | OFF | OFF | ON | OFF | OFF | ON | ON | OFF | OFF |
| 823 = | OFF | OFF | OFF | ON | OFF | OFF | ON | ON | OFF | OFF |
| 824 = | ON | ON | ON | OFF | OFF | OFF | ON | ON | OFF | OFF |
| 825 = | OFF | ON | ON | OFF | OFF | OFF | ON | ON | OFF | OFF |
| 826 = | ON | OFF | ON | OFF | OFF | OFF | ON | ON | OFF | OFF |
| 827 = | OFF | OFF | ON | OFF | OFF | OFF | ON | ON | OFF | OFF |
| 828 = | ON | ON | OFF | OFF | OFF | OFF | ON | ON | OFF | OFF |
| 829 = | OFF | ON | OFF | OFF | OFF | OFF | ON | ON | OFF | OFF |
| 830 = | ON | OFF | OFF | OFF | OFF | OFF | ON | ON | OFF | OFF |
| 831 = | OFF | OFF | OFF | OFF | OFF | OFF | ON | ON | OFF | OFF |
| 832 = | ON | ON | ON | ON | ON | ON | OFF | ON | OFF | OFF |

Table 21, Ametek Speedometer Calibration Codes, 796 to 832

| Ametek Speedometer Calibration Codes, 833 to 869 | | | | | | | | | | |
|--|-----|-----|-----|----|----|----|-----|----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 833 = | OFF | ON | ON | ON | ON | ON | OFF | ON | OFF | OFF |
| 834 = | ON | OFF | ON | ON | ON | ON | OFF | ON | OFF | OFF |
| 835 = | OFF | OFF | ON | ON | ON | ON | OFF | ON | OFF | OFF |
| 836 = | ON | ON | OFF | ON | ON | ON | OFF | ON | OFF | OFF |
| 837 = | OFF | ON | OFF | ON | ON | ON | OFF | ON | OFF | OFF |
| 838 = | ON | OFF | OFF | ON | ON | ON | OFF | ON | OFF | OFF |

| Ametek Speedometer Calibration Codes, 833 to 869 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 839 = | OFF | OFF | OFF | ON | ON | ON | OFF | ON | OFF | OFF |
| 840 = | ON | ON | ON | OFF | ON | ON | OFF | ON | OFF | OFF |
| 841 = | OFF | ON | ON | OFF | ON | ON | OFF | ON | OFF | OFF |
| 842 = | ON | OFF | ON | OFF | ON | ON | OFF | ON | OFF | OFF |
| 843 = | OFF | OFF | ON | OFF | ON | ON | OFF | ON | OFF | OFF |
| 844 = | ON | ON | OFF | OFF | ON | ON | OFF | ON | OFF | OFF |
| 845 = | OFF | ON | OFF | OFF | ON | ON | OFF | ON | OFF | OFF |
| 846 = | ON | OFF | OFF | OFF | ON | ON | OFF | ON | OFF | OFF |
| 847 = | OFF | OFF | OFF | OFF | ON | ON | OFF | ON | OFF | OFF |
| 848 = | ON | ON | ON | ON | OFF | ON | OFF | ON | OFF | OFF |
| 849 = | OFF | ON | ON | ON | OFF | ON | OFF | ON | OFF | OFF |
| 850 = | ON | OFF | ON | ON | OFF | ON | OFF | ON | OFF | OFF |
| 851 = | OFF | OFF | ON | ON | OFF | ON | OFF | ON | OFF | OFF |
| 852 = | ON | ON | OFF | ON | OFF | ON | OFF | ON | OFF | OFF |
| 853 = | OFF | ON | OFF | ON | OFF | ON | OFF | ON | OFF | OFF |
| 854 = | ON | OFF | OFF | ON | OFF | ON | OFF | ON | OFF | OFF |
| 855 = | OFF | OFF | OFF | ON | OFF | ON | OFF | ON | OFF | OFF |
| 856 = | ON | ON | ON | OFF | OFF | ON | OFF | ON | OFF | OFF |
| 857 = | OFF | ON | ON | OFF | OFF | ON | OFF | ON | OFF | OFF |
| 858 = | ON | OFF | ON | OFF | OFF | ON | OFF | ON | OFF | OFF |
| 859 = | OFF | OFF | ON | OFF | OFF | ON | OFF | ON | OFF | OFF |
| 860 = | ON | ON | OFF | OFF | OFF | ON | OFF | ON | OFF | OFF |
| 861 = | OFF | ON | OFF | OFF | OFF | ON | OFF | ON | OFF | OFF |
| 862 = | ON | OFF | OFF | OFF | OFF | ON | OFF | ON | OFF | OFF |
| 863 = | OFF | OFF | OFF | OFF | OFF | ON | OFF | ON | OFF | OFF |
| 864 = | ON | ON | ON | ON | ON | OFF | OFF | ON | OFF | OFF |
| 865 = | OFF | ON | ON | ON | ON | OFF | OFF | ON | OFF | OFF |
| 866 = | ON | OFF | ON | ON | ON | OFF | OFF | ON | OFF | OFF |
| 867 = | OFF | OFF | ON | ON | ON | OFF | OFF | ON | OFF | OFF |
| 868 = | ON | ON | OFF | ON | ON | OFF | OFF | ON | OFF | OFF |
| 869 = | OFF | ON | OFF | ON | ON | OFF | OFF | ON | OFF | OFF |

Table 22, Ametek Speedometer Calibration Codes, 833 to 869

| Ametek Speedometer Calibration Codes, 870 to 906 | | | | | | | | | | |
|--|----|-----|-----|----|----|-----|-----|----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 870 = | ON | OFF | OFF | ON | ON | OFF | OFF | ON | OFF | OFF |

Specifications

| Ametek Speedometer Calibration Codes, 870 to 906 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 871 = | OFF | OFF | OFF | ON | ON | OFF | OFF | ON | OFF | OFF |
| 872 = | ON | ON | ON | OFF | ON | OFF | OFF | ON | OFF | OFF |
| 873 = | OFF | ON | ON | OFF | ON | OFF | OFF | ON | OFF | OFF |
| 874 = | ON | OFF | ON | OFF | ON | OFF | OFF | ON | OFF | OFF |
| 875 = | OFF | OFF | ON | OFF | ON | OFF | OFF | ON | OFF | OFF |
| 876 = | ON | ON | OFF | OFF | ON | OFF | OFF | ON | OFF | OFF |
| 877 = | OFF | ON | OFF | OFF | ON | OFF | OFF | ON | OFF | OFF |
| 878 = | ON | OFF | OFF | OFF | ON | OFF | OFF | ON | OFF | OFF |
| 879 = | OFF | OFF | OFF | OFF | ON | OFF | OFF | ON | OFF | OFF |
| 880 = | ON | ON | ON | ON | OFF | OFF | OFF | ON | OFF | OFF |
| 881 = | OFF | ON | ON | ON | OFF | OFF | OFF | ON | OFF | OFF |
| 882 = | ON | OFF | ON | ON | OFF | OFF | OFF | ON | OFF | OFF |
| 883 = | OFF | OFF | ON | ON | OFF | OFF | OFF | ON | OFF | OFF |
| 884 = | ON | ON | OFF | ON | OFF | OFF | OFF | ON | OFF | OFF |
| 885 = | OFF | ON | OFF | ON | OFF | OFF | OFF | ON | OFF | OFF |
| 886 = | ON | OFF | OFF | ON | OFF | OFF | OFF | ON | OFF | OFF |
| 887 = | OFF | OFF | OFF | ON | OFF | OFF | OFF | ON | OFF | OFF |
| 888 = | ON | ON | ON | OFF | OFF | OFF | OFF | ON | OFF | OFF |
| 889 = | OFF | ON | ON | OFF | OFF | OFF | OFF | ON | OFF | OFF |
| 890 = | ON | OFF | ON | OFF | OFF | OFF | OFF | ON | OFF | OFF |
| 891 = | OFF | OFF | ON | OFF | OFF | OFF | OFF | ON | OFF | OFF |
| 892 = | ON | ON | OFF | OFF | OFF | OFF | OFF | ON | OFF | OFF |
| 893 = | OFF | ON | OFF | OFF | OFF | OFF | OFF | ON | OFF | OFF |
| 894 = | ON | OFF | OFF | OFF | OFF | OFF | OFF | ON | OFF | OFF |
| 895 = | OFF | OFF | OFF | OFF | OFF | OFF | OFF | ON | OFF | OFF |
| 896 = | ON | ON | ON | ON | ON | ON | ON | OFF | OFF | OFF |
| 897 = | OFF | ON | ON | ON | ON | ON | ON | OFF | OFF | OFF |
| 898 = | ON | OFF | ON | ON | ON | ON | ON | OFF | OFF | OFF |
| 899 = | OFF | OFF | ON | ON | ON | ON | ON | OFF | OFF | OFF |
| 900 = | ON | ON | OFF | ON | ON | ON | ON | OFF | OFF | OFF |
| 901 = | OFF | ON | OFF | ON | ON | ON | ON | OFF | OFF | OFF |
| 902 = | ON | OFF | OFF | ON | ON | ON | ON | OFF | OFF | OFF |
| 903 = | OFF | OFF | OFF | ON | ON | ON | ON | OFF | OFF | OFF |
| 904 = | ON | ON | ON | OFF | ON | ON | ON | OFF | OFF | OFF |
| 905 = | OFF | ON | ON | OFF | ON | ON | ON | OFF | OFF | OFF |

| Ametek Speedometer Calibration Codes, 870 to 906 | | | | | | | | | | |
|--|----|-----|----|-----|----|----|----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 906 = | ON | OFF | ON | OFF | ON | ON | ON | OFF | OFF | OFF |

Table 23, Ametek Speedometer Calibration Codes, 870 to 906

| Ametek Speedometer Calibration Codes, 907 to 943 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 907 = | OFF | OFF | ON | OFF | ON | ON | ON | OFF | OFF | OFF |
| 908 = | ON | ON | OFF | OFF | ON | ON | ON | OFF | OFF | OFF |
| 909 = | OFF | ON | OFF | OFF | ON | ON | ON | OFF | OFF | OFF |
| 910 = | ON | OFF | OFF | OFF | ON | ON | ON | OFF | OFF | OFF |
| 911 = | OFF | OFF | OFF | OFF | ON | ON | ON | OFF | OFF | OFF |
| 912 = | ON | ON | ON | ON | OFF | ON | ON | OFF | OFF | OFF |
| 913 = | OFF | ON | ON | ON | OFF | ON | ON | OFF | OFF | OFF |
| 914 = | ON | OFF | ON | ON | OFF | ON | ON | OFF | OFF | OFF |
| 915 = | OFF | OFF | ON | ON | OFF | ON | ON | OFF | OFF | OFF |
| 916 = | ON | ON | OFF | ON | OFF | ON | ON | OFF | OFF | OFF |
| 917 = | OFF | ON | OFF | ON | OFF | ON | ON | OFF | OFF | OFF |
| 918 = | ON | OFF | OFF | ON | OFF | ON | ON | OFF | OFF | OFF |
| 919 = | OFF | OFF | OFF | ON | OFF | ON | ON | OFF | OFF | OFF |
| 920 = | ON | ON | ON | OFF | OFF | ON | ON | OFF | OFF | OFF |
| 921 = | OFF | ON | ON | OFF | OFF | ON | ON | OFF | OFF | OFF |
| 922 = | ON | OFF | ON | OFF | OFF | ON | ON | OFF | OFF | OFF |
| 923 = | OFF | OFF | ON | OFF | OFF | ON | ON | OFF | OFF | OFF |
| 924 = | ON | ON | OFF | OFF | OFF | ON | ON | OFF | OFF | OFF |
| 925 = | OFF | ON | OFF | OFF | OFF | ON | ON | OFF | OFF | OFF |
| 926 = | ON | OFF | OFF | OFF | OFF | ON | ON | OFF | OFF | OFF |
| 927 = | OFF | OFF | OFF | OFF | OFF | ON | ON | OFF | OFF | OFF |
| 928 = | ON | ON | ON | ON | ON | OFF | ON | OFF | OFF | OFF |
| 929 = | OFF | ON | ON | ON | ON | OFF | ON | OFF | OFF | OFF |
| 930 = | ON | OFF | ON | ON | ON | OFF | ON | OFF | OFF | OFF |
| 931 = | OFF | OFF | ON | ON | ON | OFF | ON | OFF | OFF | OFF |
| 932 = | ON | ON | OFF | ON | ON | OFF | ON | OFF | OFF | OFF |
| 933 = | OFF | ON | OFF | ON | ON | OFF | ON | OFF | OFF | OFF |
| 934 = | ON | OFF | OFF | ON | ON | OFF | ON | OFF | OFF | OFF |
| 935 = | OFF | OFF | OFF | ON | ON | OFF | ON | OFF | OFF | OFF |
| 936 = | ON | ON | ON | OFF | ON | OFF | ON | OFF | OFF | OFF |
| 937 = | OFF | ON | ON | OFF | ON | OFF | ON | OFF | OFF | OFF |

Specifications

| Ametek Speedometer Calibration Codes, 907 to 943 | | | | | | | | | | |
|--|-----|-----|-----|-----|----|-----|----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 938 = | ON | OFF | ON | OFF | ON | OFF | ON | OFF | OFF | OFF |
| 939 = | OFF | OFF | ON | OFF | ON | OFF | ON | OFF | OFF | OFF |
| 940 = | ON | ON | OFF | OFF | ON | OFF | ON | OFF | OFF | OFF |
| 941 = | OFF | ON | OFF | OFF | ON | OFF | ON | OFF | OFF | OFF |
| 942 = | ON | OFF | OFF | OFF | ON | OFF | ON | OFF | OFF | OFF |
| 943 = | OFF | OFF | OFF | OFF | ON | OFF | ON | OFF | OFF | OFF |

Table 24, Ametek Speedometer Calibration Codes, 907 to 943

| Ametek Speedometer Calibration Codes, 944 to 980 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 944 = | ON | ON | ON | ON | OFF | OFF | ON | OFF | OFF | OFF |
| 945 = | OFF | ON | ON | ON | OFF | OFF | ON | OFF | OFF | OFF |
| 946 = | ON | OFF | ON | ON | OFF | OFF | ON | OFF | OFF | OFF |
| 947 = | OFF | OFF | ON | ON | OFF | OFF | ON | OFF | OFF | OFF |
| 948 = | ON | ON | OFF | ON | OFF | OFF | ON | OFF | OFF | OFF |
| 949 = | OFF | ON | OFF | ON | OFF | OFF | ON | OFF | OFF | OFF |
| 950 = | ON | OFF | OFF | ON | OFF | OFF | ON | OFF | OFF | OFF |
| 951 = | OFF | OFF | OFF | ON | OFF | OFF | ON | OFF | OFF | OFF |
| 952 = | ON | ON | ON | OFF | OFF | OFF | ON | OFF | OFF | OFF |
| 953 = | OFF | ON | ON | OFF | OFF | OFF | ON | OFF | OFF | OFF |
| 954 = | ON | OFF | ON | OFF | OFF | OFF | ON | OFF | OFF | OFF |
| 955 = | OFF | OFF | ON | OFF | OFF | OFF | ON | OFF | OFF | OFF |
| 956 = | ON | ON | OFF | OFF | OFF | OFF | ON | OFF | OFF | OFF |
| 957 = | OFF | ON | OFF | OFF | OFF | OFF | ON | OFF | OFF | OFF |
| 958 = | OFF | ON | OFF | OFF | OFF | OFF | ON | OFF | OFF | OFF |
| 959 = | OFF | OFF | OFF | OFF | OFF | OFF | ON | OFF | OFF | OFF |
| 960 = | ON | ON | ON | ON | ON | ON | OFF | OFF | OFF | OFF |
| 961 = | OFF | ON | ON | ON | ON | ON | OFF | OFF | OFF | OFF |
| 962 = | ON | OFF | ON | ON | ON | ON | OFF | OFF | OFF | OFF |
| 963 = | OFF | OFF | ON | ON | ON | ON | OFF | OFF | OFF | OFF |
| 964 = | ON | ON | OFF | ON | ON | ON | OFF | OFF | OFF | OFF |
| 965 = | OFF | ON | OFF | ON | ON | ON | OFF | OFF | OFF | OFF |
| 966 = | ON | OFF | OFF | ON | ON | ON | OFF | OFF | OFF | OFF |
| 967 = | OFF | OFF | OFF | ON | ON | ON | OFF | OFF | OFF | OFF |
| 968 = | ON | ON | ON | OFF | ON | ON | OFF | OFF | OFF | OFF |
| 969 = | OFF | ON | ON | OFF | ON | ON | OFF | OFF | OFF | OFF |

| Ametek Speedometer Calibration Codes, 944 to 980 | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|----|-----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 970 = | ON | OFF | ON | OFF | ON | ON | OFF | OFF | OFF | OFF |
| 971 = | OFF | OFF | ON | OFF | ON | ON | OFF | OFF | OFF | OFF |
| 972 = | ON | ON | OFF | OFF | ON | ON | OFF | OFF | OFF | OFF |
| 973 = | OFF | ON | OFF | OFF | ON | ON | OFF | OFF | OFF | OFF |
| 974 = | ON | OFF | OFF | OFF | ON | ON | OFF | OFF | OFF | OFF |
| 975 = | OFF | OFF | OFF | OFF | ON | ON | OFF | OFF | OFF | OFF |
| 976 = | ON | ON | ON | ON | OFF | ON | OFF | OFF | OFF | OFF |
| 977 = | OFF | ON | ON | ON | OFF | ON | OFF | OFF | OFF | OFF |
| 978 = | ON | OFF | ON | ON | OFF | ON | OFF | OFF | OFF | OFF |
| 979 = | OFF | OFF | ON | ON | OFF | ON | OFF | OFF | OFF | OFF |
| 980 = | ON | ON | OFF | ON | OFF | ON | OFF | OFF | OFF | OFF |

Table 25, Ametek Speedometer Calibration Codes, 944 to 980

| Ametek Speedometer Calibration Codes, 981 to 1023 | | | | | | | | | | |
|---|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 981 = | OFF | ON | OFF | ON | OFF | ON | OFF | OFF | OFF | OFF |
| 982 = | ON | OFF | OFF | ON | OFF | ON | OFF | OFF | OFF | OFF |
| 983 = | OFF | OFF | OFF | ON | OFF | ON | OFF | OFF | OFF | OFF |
| 984 = | ON | ON | ON | OFF | OFF | ON | OFF | OFF | OFF | OFF |
| 985 = | OFF | ON | ON | OFF | OFF | ON | OFF | OFF | OFF | OFF |
| 986 = | ON | OFF | ON | OFF | OFF | ON | OFF | OFF | OFF | OFF |
| 987 = | OFF | OFF | ON | OFF | OFF | ON | OFF | OFF | OFF | OFF |
| 988 = | ON | ON | OFF | OFF | OFF | ON | OFF | OFF | OFF | OFF |
| 989 = | OFF | ON | OFF | OFF | OFF | ON | OFF | OFF | OFF | OFF |
| 990 = | ON | OFF | OFF | OFF | OFF | ON | OFF | OFF | OFF | OFF |
| 991 = | OFF | OFF | OFF | OFF | OFF | ON | OFF | OFF | OFF | OFF |
| 992 = | ON | ON | ON | ON | ON | OFF | OFF | OFF | OFF | OFF |
| 993 = | OFF | ON | ON | ON | ON | OFF | OFF | OFF | OFF | OFF |
| 994 = | ON | OFF | ON | ON | ON | OFF | OFF | OFF | OFF | OFF |
| 995 = | OFF | OFF | ON | ON | ON | OFF | OFF | OFF | OFF | OFF |
| 996 = | ON | ON | OFF | ON | ON | OFF | OFF | OFF | OFF | OFF |
| 997 = | OFF | ON | OFF | ON | ON | OFF | OFF | OFF | OFF | OFF |
| 998 = | ON | OFF | OFF | ON | ON | OFF | OFF | OFF | OFF | OFF |
| 999 = | OFF | OFF | OFF | ON | ON | OFF | OFF | OFF | OFF | OFF |
| 1000 = | ON | ON | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF |
| 1001 = | OFF | ON | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF |

Specifications

| Ametek Speedometer Calibration Codes, 981 to 1023 | | | | | | | | | | |
|---|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| PPM/120 | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 1002 = | ON | OFF | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF |
| 1003 = | OFF | OFF | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF |
| 1004 = | ON | ON | OFF | OFF | ON | OFF | OFF | OFF | OFF | OFF |
| 1005 = | OFF | ON | OFF | OFF | ON | OFF | OFF | OFF | OFF | OFF |
| 1006 = | ON | OFF | OFF | OFF | ON | OFF | OFF | OFF | OFF | OFF |
| 1007 = | OFF | OFF | OFF | OFF | ON | OFF | OFF | OFF | OFF | OFF |
| 1008 = | ON | ON | ON | ON | OFF | OFF | OFF | OFF | OFF | OFF |
| 1009 = | OFF | ON | ON | ON | OFF | OFF | OFF | OFF | OFF | OFF |
| 1010 = | ON | OFF | ON | ON | OFF | OFF | OFF | OFF | OFF | OFF |
| 1011 = | OFF | OFF | ON | ON | OFF | OFF | OFF | OFF | OFF | OFF |
| 1012 = | ON | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF |
| 1013 = | OFF | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF |
| 1014 = | ON | OFF | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF |
| 1015 = | OFF | OFF | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF |
| 1016 = | ON | ON | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| 1017 = | OFF | ON | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| 1018 = | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| 1019 = | OFF | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| 1020 = | ON | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| 1021 = | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| 1022 = | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| 1023 = | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF |

Table 26, Ametek Speedometer Calibration Codes, 981 to 1023